

<b>DTC</b>	<b>C1531 / 31</b>	<b>VGRS ECU Malfunction</b>
------------	-------------------	-----------------------------

## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1531/31	The system detects a malfunction inside the ECU.	•VGRS ECU

## INSPECTION PROCEDURE

<b>1</b>	<b>Check vehicle conditions when the warning light comes on.</b>
----------	--

### CHECK:

Just before the light comes on, was the engine stalled, or the battery dead or the terminal disconnected?

**NO**

**Replace VGRS ECU.**

**YES**

<b>2</b>	<b>Record and clear the DTCs. Perform the steering angle sensor initialization.</b>
----------	---

Did the DTC C1531/31 reappear?

**YES**

**Replace VGRS ECU.**

**NO**

**Condition corrected by the steering angle initialization.**