

**16. Touch switch does not function. (A/C control screen only)****INSPECTION PROCEDURE**

1 Display check mode (Touch switch, Touch point screen).

NG

Replace the multi-display.

OK

2 Check "AVC-LAN communication circuit" (See page DI-1215).

NG

Replace or repair AVC-LAN circuit.

OK

3 Check "Gateway ECU (AVC-LAN adopter) circuit" (See page DI-1221).

NG

Repair or replace wire harness and connector

OK

Check and replace A/C amplifier (Center ECU).