


## Neutral Start Switch Circuit Malfunction

### CIRCUIT DESCRIPTION

The neutral start switch detects the shift lever range and sends signals to the Engine and ECT ECU (2UZ-FE, 1FZ-FE) or ECT ECU (1HZ, 1HD-T, 1HD-FTE).


The Engine and ECT ECU receives signals (NSW, R, 2 and L) or ECT ECU receives signals (P, R, N, 2 and L) from the neutral start switch. When the signal is not sent to the Engine and ECT ECU (2UZ-FE, 1FZ-FE) or ECT ECU (1HZ, 1HD-T, 1HD-FTE) from the neutral start switch, the Engine and ECT ECU (2UZ-FE, 1FZ-FE) or ECT ECU (1HZ, 1HD-T, 1HD-FTE) judges that the shift lever is in D range.

## WIRING DIAGRAM




D03946

## 2UZ-FE (RHD)




D03947

## 1FZ-FE (LHD)




D03948

## 1FZ-FE (RHD)




D03949

## 1HD-FTE (LHD)




D03950

## 1HD-FTE (RHD)



D03951


## 1HZ (LHD), 1HD-T (LHD)



D03952



## 1HZ (RHD)



D03953

## INSPECTION PROCEDURE

### HINT:

In case of using the hand-held tester, start the inspection from step 1 and in case of not using the hand-held tester, start from step 2.

**1 Read PNP, REVERSE, DRIVE, 2ND and LOW signals.**

### PREPARATION:

- (a) Remove the DLC3 cover.
- (b) Connect a hand-held tester to the DLC3.
- (c) Turn the ignition switch ON and hand-held tester main switch ON.

### CHECK:

Shift lever into the P, R, N, D, 2 and L ranges, and read the PNP, REVERSE, DRIVE, 2ND and LOW signals on the hand-held tester.

### OK:

Shift range	Signal
P/N	PNP [OFF] → ON
R	REVERSE [OFF] → ON
D	DRIVE [OFF] → ON
2	2ND : OFF → ON
L	LOW : OFF → ON


**OK**

**Check and replace the Engine and ECT ECU or ECT ECU (See page IN-35).**

**NG**

**Go to step 3.**

## 2 Measure voltage between each terminals of NSW, R, 2, and L of Engine and ECT ECU or P, R, N, 2 and L of ECT ECU and body ground.



### PREPARATION:

Turn the Ignition switch ON.

### CHECK:

Measure voltage between each terminals NSW, R, N, 2 and L of Engine and ECT ECU and body ground when the shift lever is shifted to the following positions.

### OK:

#### 2UZ-FE:

Tester connection	Condition	Specified condition
NSW - Body ground	Shift lever range: P, N	No battery positive voltage
R - Body ground	Shift lever range: R	Battery positive voltage*
D - Body ground	Shift lever range: D	Battery positive voltage
2 - Body ground	Shift lever range: 2	Battery positive voltage
L - Body ground	Shift lever range: L	Battery positive voltage

#### 1FZ-FE:

Tester connection	Condition	Specified condition
NSW - Body ground	Shift lever range: P, N	No battery positive voltage
R - Body ground	Shift lever range: R	Battery positive voltage*
2 - Body ground	Shift lever range: 2	Battery positive voltage
L - Body ground	Shift lever range: L	Battery positive voltage

#### 1HZ, 1HD-T, 1HD-FTE:

Tester connection	Condition	Specified condition
P - Body ground	Shift lever range: P	Battery positive voltage
N - Body ground	Shift lever range: N	Battery positive voltage
R - Body ground	Shift lever range: R	Battery positive voltage*
2 - Body ground	Shift lever range: 2	Battery positive voltage
L - Body ground	Shift lever range: L	Battery positive voltage


### HINT:

\*: The voltage will drop slightly due to lighting up of the back up light.

OK

Check and replace the Engine and ECT ECU or ECT ECU (See page IN-35).

NG

**3 Check neutral start switch.****PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the neutral start switch.

**CHECK:**

Check continuity between each terminal shown below when the shift lever is moved to each range.

**OK:**

Shift Range	Terminal No. to continuity	Terminal No. to continuity
P	4 – 7	5 – 6
R	4 – 3	–
N	4 – 10	5 – 6
D	4 – 9	–
2	2 – 4	–
L	2 – 3	–

**NG****Replace the neutral start switch.****OK**

**Repair or replace harness and connector between battery and neutral start switch, neutral start switch and Engine and ECT ECU or ECT ECU (See page IN-35).**