

**24. Driving direction is opposite to moving direction of vehicle position mark.****INSPECTION PROCEDURE**

**1**      **Navigation check mode (vehicle signal check mode REV).**

**OK**

**Replace the navigation ECU.**

**NG**

**2**      **Check the navigation ECU.**

**CHECK:**

Check terminal REV.

**OK:**

**REV: See "Navigation ECU" of "TERMINAL OF ECU".**

**OK**

**Replace the navigation ECU.**

**NG**

**Replace or repair wire harness.**