

PROBLEM SYMPTOMS TABLE

POWER DOOR LOCK CONTROL SYSTEM:

Symptom	Suspect Area	See page
All the doors can not be locked or unlocked.	1. Power source circuit 2. Theft deterrent ECU 3. Power window master switch (Driver door ECU)	DI-1070 DI-825 BE-51
Driver side door lock does not operate.	1. Door lock motor circuit 2. Power window master switch (Driver door ECU) 3. Theft deterrent ECU	DI-1086 BE-51 DI-825
Door key related function cannot be done.	1. Door key lock and unlock switch circuit 2. Door courtesy light and courtesy switch circuit 3. Theft deterrent ECU 4. Power window master switch (Driver door ECU)	DI-1073 DI-1008 DI-825 BE-51
Key confinement prevention function does not operate.	1. Door courtesy light and courtesy switch circuit 2. Door unlock detection switch circuit 3. Theft deterrent ECU 4. Power window master switch (Driver door ECU)	DI-1008 DI-1081 DI-825 BE-51

POWER WINDOW CONTROL SYSTEM:

Symptom	Suspect Area	See page
All the power window does not operate.	1. Power source circuit 2. Power window master switch (Driver door ECU)	DI-1070 BE-51
Driver side power window does not operate.	1. Power window motor circuit 2. Power window master switch (Driver door ECU)	DI-1086 BE-51
Jam protection function and auto up or down function does not operate.	1. Jam protection limit and pulse switch circuit (Master switch) 2. Jam protection limit and pulse switch circuit (Front RH) 3. Jam protection limit and pulse switch circuit (Rear RL / RR) 4. Power window master switch (Driver door ECU) 5. Theft deterrent ECU	DI-1066 DI-1068 DI-1091 DI-1100 DI-1096 BE-51 DI-825
Window lock function does not operate.	1. Power window master switch (Driver door ECU)	BE-51
Remote control of all windows (Except driver side) does not operate with master switch. (Window operates normally with each of master switch.)	1. Power window master switch circuit (Driver door ECU)	BE-51
The key related power window operations cannot be done with driver door key cylinder. (Master switch operation is normal.)	1. Door key lock and unlock switch circuit 2. Door courtesy light and courtesy switch circuit 3. Power window master switch (Driver door ECU)	DI-1073 DI-1008 BE-51
Power window does not operate with keyless entry transmitter. (Windows operate normally with master switch.)	1. Inspect wireless door lock control system 2. Replace Power window master switch (Driver door ECU) 3. Theft deterrent ECU	DI-808 – DI-825