

INSTALLATION

Installation is in the reverse order of removal (See page BR-92).

AFTER INSTALLATION, CHECK SPEED SENSOR SIGNAL (See page DI-312).