


## CIRCUIT INSPECTION

### Tc Terminal Circuit

### CIRCUIT DESCRIPTION

Connecting terminals Tc and E<sub>1</sub> of the check connector or Tc and CG of DLC3 causes the ECU to display the DTC by flashing the ABS warning light.


### WIRING DIAGRAM



F14375

## INSPECTION PROCEDURE

- 1 Check voltage between terminals Tc and E<sub>1</sub> of check connector or Tc and CG of DLC3.

**PREPARATION:**

Turn the Ignition switch ON.

**CHECK:**

Measure voltage between terminal Tc and E<sub>1</sub> of check connector or Tc and CG of DLC3.

**OK:**

**Voltage: 10 – 14 V**

OK

If ABS warning light does not blink even after Tc and E<sub>1</sub> of check connector or Tc and CG of DLC3 are connected, the ECU may be defective.

NG

- 2 Ignition switch OFF, and check for open and short circuit in harness and connector between ABS ECU and check connector or DLC3, check connector or DLC3 and body ground (See page IN-35).

NG

Repair or replace harness or connector.

OK

Check and replace ABS ECU.