


NEUTRAL START SWITCH ON-VEHICLE REPAIR

AT09I-01

1. **IFS Only:**
REMOVE NO.2 ENGINE UNDER COVER
2. **1HD-FTE Only:**
REMOVE TRANSMISSION UNDER COVER
3. **DISCONNECT NEUTRAL START SWITCH CONNECTOR**



4. **REMOVE NEUTRAL START SWITCH**
 - (a) Using a screwdriver, pry off the lock washer.
 - (b) Remove the nut and lock washer.
 - (c) Remove the 2 bolts and neutral start switch.
5. **INSTALL NEUTRAL START SWITCH**
 - (a) Install the neutral start switch with the 2 bolts.
Torque: 13 N·m (130 kgf·cm, 9 ft·lbf)
 - (b) Install a new lock washer and nut.
Torque: 3.9 N·m (40 kgf·cm, 35 in·lbf)
 - (c) Stake the nut with the lock washer.
 - (d) Adjust the neutral start switch ([See page DI-80](#)).
6. **CONNECT NEUTRAL START SWITCH CONNECTOR**
7. **1HD-FTE Only:**
REMOVE TRANSMISSION UNDER COVER
8. **IFS Only:**
INSTALL NO.2 ENGINE UNDER COVER