

# 27. The Cellular Phone cannot Send/Receive

## INSPECTION PROCEDURE


1	Check bluetooth settings.
---	---------------------------

Check if the BLUETOOTH settings are correct.

**OK:**  
BLUETOOTH settings are correct.

NG

Set settings correctly.



2	Check cellular phone.
---	-----------------------


Check if the cellular phone is BLUETOOTH capable.

HINT:  
Some versions of BLUETOOTH capable cellular phone may not be compatible.

**OK:**  
The phone is BLUETOOTH capable.

NG

END (Only a bluetooth capable cellular phone can be used)



**3 Check settings**

Check if the cellular phone functions.

**HINT:**

- The cellular phone is unable to call under any of the following conditions.
- The cellular phone is locked.
- The directory is being transferred.
- The line is crossed.
- Transmission is requested.
- The power is off.
- The cellular phone is not connected to BLUETOOTH ("BT" is displayed while a connection is present).

**OK:**

**No of the above conditions exist.**

**NG**

**Set setting correctly.**

**OK**

**4 Check cellular phone.**

Check if the cellular phone can call.

**HINT:**

When the battery charge is low, calls cannot be made or received.

**OK:**

**The cellular phone can call.**

**NG**

**Replace cellular phone.**

**OK**

**5 Check reception**

- (a) Put a cellular phone into a receiving state.
- (b) Place the cellular phone close to the multi-display.
- (c) Check if the cellular phone has reception according to the multi-display.

**OK:**

**The cellular phone has reception.**

**NG****Replace multi-display.****OK**

**Go to "Own voice cannot be heard, quiet or distorted" (See [page DI-254](#))**