

## INSPECTION

### 1. CHECK EXHAUST PIPE ASSEMBLY

- (a) Check the connections for looseness or damage.
- (b) Check the clamps for weakness, cracks or damage.

### 2. INSPECT TWC

Check for dents or damage.

If any part of protector is damaged or dented to the extent that it contacts the TWC, repair or replace it.

### 3. INSPECT HEAT INSULATOR

- (a) Check the heat insulator for damage.
- (b) Check for adequate clearance between the TWC and heat insulator.