

7. Navigation screen not stabilized (Synchronous error).

INSPECTION PROCEDURE

| | |
|---|---------------------------|
| 1 | Check the navigation ECU. |
|---|---------------------------|

CHECK:

Check terminals +B.

OK:**+B: 10 – 14 V****CHECK:**

Check terminal ACC when turn ignition switch ACC or ON position.

OK:**ACC: 10 – 14 V****CHECK:**

Check terminal SYNC, VR or VG.

OK:**SYNC, VR, VG: See "Navigation ECU" of "TERMINAL OF ECU"****NG****Replace the wire harness when all terminals are faulty. Replace the wire harness when the SYNC terminal is faulty.****OK****Replace the multi-display.**