

## INSPECTION

### INSPECT WASHER NOZZLE

- (a) While operating the washer, check if the point where the washer fluid hits the windshield is within the range indicated by the hatched line.

**A: Approx. 259 mm (10.20 in.)**

**B: Approx. 138 mm (5.43 in.)**

**C: Approx. 24 mm (0.94 in.)**

**D: Approx. 108 mm (4.25 in.)**

**E: Approx. 437 mm (17.20 in.)**

**F: Approx. 32 mm (1.26 in.)**

**G: Approx. 24 mm (0.94 in.)**

**H: Approx. 197 mm (7.76 in.)**

**I: Approx. 27 mm (1.06 in.)**

**J: Approx. 395 mm (15.55 in.)**

**K: Approx. 360 mm (14.17 in.)**

**L: Approx. 79 mm (3.11 in.)**

**M: Approx. 121 mm (4.76 in.)**

**N: Approx. 31 mm (1.22 in.)**

**O: Approx. 404 mm (15.91 in.)**

**P: Approx. 181 mm (7.13 in.)**

**Q: Approx. 26 mm (1.02 in.)**

**R: Approx. 24 mm (0.94 in.)**

**S: Approx. 56 mm (2.20 in.)**

**T: Approx. 185 mm (7.28 in.)**

- (b) Check that the lower point where the washer fluid hits the windshield is within the range of the wiping pattern (the area of the glass which is wiped by the blades).

