

<b>DTC</b>	<b>B1272/72</b>	<b>Power seat ECU communication stop (w/Seat memory vehicle only)</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION

This DTC is output when communication stops between power seat ECU and Body No.1 ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1272/72	No communication from seat ECU more than 10 seconds.	<ul style="list-style-type: none"> <li>• Power seat ECU</li> <li>• Wireharness</li> </ul>

## WIRING DIAGRAM

See page DI-836.

## INSPECTION PROCEDURE

<b>1</b>	<b>Check power seat ECU.</b>
----------	------------------------------

### CHECK:

Check that the operation of front vertical and rear vertical is normal.

### HINT:


With this inspection, the power seat ECU CPU can be diagnosed if it works normally or not.

**NG**

**Replace the power seat ECU.**

**OK**

## 2 Check wireharness



### **PREPARATION:**

Disconnect connector body ECU, power seat ECU and tilt & telescopic ECU.

### **CHECK:**

- Check continuity between terminals MPX1 of body ECU and MPX2 of power seat ECU.
- Check continuity between terminals MPX1 of power seat ECU and MPX2 of tilt & telescopic ECU.

### **OK:**

There is a continuity in wireharness.

**NG**

**Repair or replace wireharness.**

**OK**

**Replace power seat ECU.**