


# Diagnosis Circuit

## CIRCUIT DESCRIPTION


This circuit sends an signal to the ECU that outputs DTC.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check voltage between terminals SIL and CG of DLC3.



A04550

**PREPARATION:**

Turn ignition switch ON.

**CHECK:**

Measure voltage between terminals SIL and CG of DLC3.

**OK:**

Voltage: 10 – 14 V

OK

Proceed to next circuit inspection shown in problem symptom table (See page DI-893).

NG

## 2 Check harness and connector between transponder key ECU and DLC3, SIL and body ground (See page IN-38).

NG

Repair or replace harness or connector.

OK

Check and replace transponder key ECU.