


CIRCUIT DESCRIPTION

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check transponder key coil (See page BE-175).

NG

Replace transponder key coil.

OK

2 Check harness and connector between transponder key amplifier and Engine and ECT ECU.

NG

Repair or replace harness and connector.

OK

3 Does the system operate normally after replacement of transponder key amplifier?

Yes

Replace transponder key amplifier.

No

Replace Engine and ECT ECU.