

DTC	B1215 / 15	Door system communication bus malfunction (GND short)
-----	------------	---

CIRCUIT DESCRIPTION


This DTC is output when B or GND short occurs on door system communication bus. If B or GND short is detected on door system communication bus, separate it by bus cut relay in body ECU to prevent while communication buses' failure.

WIRING DIAGRAM

See page DI-836.

INSPECTION PROCEDURE

1	Check the communication circuit inside power mirror ECU.
---	--



**PREPARATION:**

Disconnect the connector power mirror ECU.


**CHECK:**

Check the DTC.


**OK:**

Code B1215/15 is not output

OK	Replace the power mirror ECU.
----	-------------------------------



## 2 Check the communication circuit inside tilt and telescopic ECU.



### PREPARATION:

- (a) Connect the connector power mirror ECU.
- (b) Disconnect the connector tilt and telescopic ECU.

### CHECK:

Check the DTC.

### OK:


Code B1215/15 is not output

OK

Replace the tilt and telescopic ECU.

NG

## 3 Check the communication circuit inside power seat ECU.



### PREPARATION:

- (a) Connect the connector tilt and telescopic ECU.
- (b) Disconnect the connector power seat ECU.

### CHECK:

Check the DTC.

### OK:


Code B1215/15 is not output

OK

Replace the power seat ECU.

NG

#### 4 Check for short circuit between body ECU and power mirror ECU.



##### **PREPARATION:**

Disconnect the connector power mirror ECU.

##### **CHECK:**

Check the DTC.

##### **OK:**


Code B1215/15 is not output

OK

Repair or replace the wire harness between and body ECU and power mirror ECU.

NG

#### 5 Check for short circuit between power mirror ECU and tilt & telescopic ECU.



##### **PREPARATION:**

Disconnect the connector tilt & telescopic ECU.

##### **CHECK:**

Check the DTC.


##### **OK:**

Code B1215/15 is not output

OK

Repair or replace the wire harness between power mirror ECU and tilt & telescopic ECU.

NG

**6 Check for short circuit between tilt & telescopic ECU and power seat ECU.****PREPARATION:**

Disconnect the connector power seat ECU.

**CHECK:**

Check the DTC.

**OK:**

Code B1215/15 is not output

**OK**

**Repair or replace the wire harness between and tilt & telescopic ECU and power seat ECU**

**NG**

**Replace the body ECU.**