

DTC	41	Fuel Tank Select Relay Circuit Malfunction (Fuel Tank Changeover Switch ON)
-----	----	---

CIRCUIT DESCRIPTION

Refer to DTC 11 (Main Fuel Pump Circuit Malfunction) on page DI-108.

DTC No.	DTC Detecting Condition	Trouble Area
41	Conditions (a), (b) and (c) continue: (a) Fuel tank changeover switch ON (Voltage of FPM5 terminal is high) (b) Voltage of FPM1 terminal is high (c) Voltage of FPM2 terminal is low	<ul style="list-style-type: none">• Open or short in fuel tank select relay circuit• Fuel tank select relay• Open or short in sub fuel pump circuit• Sub fuel pump• Short in main fuel pump circuit (+B short)


WIRING DIAGRAM

Refer to DTC 11 (Main Fuel Pump Circuit Malfunction) on page DI-108.

INSPECTION PROCEDURE


1	Check fuel tank select relay (See page FI-49).
---	--

NG	Replace fuel tank select relay.
----	---------------------------------



2	Check voltage between terminal FPM2 of engine ECU connector and body ground (See page DI-122, step 1).
---	--

OK	Go to step 4.
----	---------------



3	Check for open and short in harness and connector between fuel tank change-over switch and fuel tank select relay, fuel tank select relay and body ground (See page IN-19).
---	---

NG	Repair or replace harness and connector, and then go to step 8.
----	---



4 Check operation of subfuel pump (See page DI-122, step 5).

HINT:

If you have no hand-held tester, and then go to step 5.

OK

Go to step 7.

NG

5 Check subfuel pump (See page FI-15).

NG

Replace subfuel pump, and then go to step 8.

OK

6 Check for open or short in harness and connector between subfuel pump and fuel tank select relay (See page IN-19).

NG

Repair or replace, and then go to step 8.

OK

7 Check for open and short in harness and connector between fuel tank select relay and engine ECU, subfuel tank forcing driving relay and engine ECU (See page IN-19).

NG

Repair or replace, and then go to step 8.

OK

- | | |
|----------|---|
| 8 | Check for short in harness and connector between main fuel pump and fuel tank select relay (+B short circuit) (See page N-19). |
|----------|---|

NG

Repair or replace harness and connector.

OK

**Check and replace engine ECU
(See page N-19).**