

**15. Touch switch does not function. (Navigation screen only)**

**INSPECTION PROCEDURE**

**1** Display check mode (Touch switch, Touch point screen).

**NG**

**Replace the multi-display.**

**OK**

**2** Check "AVC-LAN communication circuit" (See page [DI-104](#)).

**NG**

**Replace or repair AVC-LAN circuit.**

**OK**

**Replace the navigation ECU.**