

## Diagnostic Connector (DLC3) Circuit


### CIRCUIT DESCRIPTION

Terminals TC and CG are located in the DLC3.

The DLC3 is located under the finish lower panel. When terminals TC and CG are connected, DTCs in normal mode or test mode can be read from the check engine warning light in the combination meter.

Also, terminal SIL is located in the DLC3. This terminal is used by the M–OBD communication with the intelligent tester II.

## WIRING DIAGRAM




P

A23878

## INSPECTION PROCEDURE

## 1 Check condition of check engine warning light.



FI2547

**PREPARATION:**

- (a) Turn the ignition switch ON.
- (b) Using SST, connect the terminals TC and CG of the DLC3.

SST 09843-18040

**CHECK:**

Check the check engine warning light condition.

**OK:****Check engine warning light: Blinking****HINT:**


If this inspection is OK and there is no intelligent tester, you do not need to do the following steps and this circuit is OK. Proceed to the next circuit inspection shown on problem symptom table (see page DI-16).

OK

Go to step 7.

NG

## 2 Check voltage between terminals TC and CG of DLC3.



A04971

**PREPARATION:**

Turn the ignition switch ON.

**CHECK:**

Measure the voltage between terminals TC and CG of the DLC3.

**OK:****Voltage: 9 to 14 V**

OK

Go to step 5.

NG

**3 Check resistance between terminal CG of DLC3 and body ground.**

**NG**

**Repair or replace harness or connector.**

**OK**

**4 Check for open and short in harness and connector between terminal TC of DLC3 and terminal TC of engine ECU (See page IN-19).**


**NG**

**Repair or replace harness or connector.**

**OK**

**Check and replace engine ECU (See page IN-19).**

**5 Check voltage between terminal W of engine ECU connector and body ground.**



**PREPARATION:**

- (a) Remove the glove compartment door.
- (b) Disconnect the E19 connector of the engine ECU.
- (c) Turn the ignition switch ON.

**CHECK:**

Measure the voltage between terminal W of the engine ECU connector and body ground.

**OK:**

**Voltage: 9 to 14 V**

**OK**

**Check and replace engine ECU (See page IN-19).**


**NG**

**6 Check bulb of check engine warning light.****NG**

Replace bulb.

**OK**

Check for open in harness and connector between terminal W of engine ECU and combination meter [\(See page IN-19\)](#).

**7 Can you read DTC (including normal DTC) using intelligent tester II?****YES**Proceed to next circuit inspection shown on problem/symptom table [\(See page DI-15\)](#).**NO****8 Check voltage between terminal BATT of DLC3 and body ground.****CHECK:**

Measure the voltage between terminal BATT of the DLC3 and body ground.

**OK:**

Voltage: 9 to 14 V

**NG**Check for open and short in harness and connector between terminal BATT of DLC3 and fusible link block [\(See page IN-19\)](#).**OK**

Check for open and short in harness and connector between terminal SIL of DLC3 and terminal SIL of engine ECU [\(See page IN-19\)](#).