


## INSPECTION


### NOTICE:

- Always use new gaskets when replacing the fuel tank or components parts.
- Apply the proper torque to all parts to be tightened.


### INSPECT FUEL LINES AND CONNECTIONS



- Check the fuel lines for cracks or leakage, and all connections for deformation.
- Check the fuel tank vapor vent system hoses and connections for looseness, sharp bends or damage.
- Check the fuel tank for deformation, cracks, fuel leakage or tank band looseness.
- Check the inlet pipe for damage or fuel leakage.




- Hose and pipe connections are shown in the illustration.




- Make sure that the hose clamps do not interfere with the tank, tubes, hoses and other parts. If a problem is found, repair or replace the parts as necessary.

#### IFS Main Tank:



Fuel Inlet Hose

#### Except IFS Main Tank:



Fuel Inlet Hose