

OPERATION

The function of the ignition system is to distribute spark to the cylinders at appropriate timing in accordance with the piston position.


IG034-01

PREPARATION

SST (SPECIAL SERVICE TOOLS)



IG00R-02



	09155-16100 Spark Plug Wrench	
---	-------------------------------	--

RECOMMENDED TOOLS

IG00S-01

	09082-00015 TOYOTA Electrical Tester	
	09200-00010 Engine Adjust Kit	

EQUIPMENT

IG00Y-02

Megger insulation resistancemeter	
Spark plug cleaner	
Torque wrench	