


## IDLE-UP SWITCH (1HZ, 1HD-T, 1HD-FTE)

### INSPECTION

AC1UT-01

#### 1. REMOVE IDLE-UP SWITCH


Using a screwdriver, pullout the switch then disconnect the connector.



#### 2. INSPECT IDLE-UP SWITCH


- (a) Inspect the illumination operation.  
Connect the positive (+) lead from the battery to terminal 1 and negative (-) lead to terminal 2 then check that the illumination lights up.

If operation is not as specified, check the bulb.



- (b) 1HD-FTE Engine w/ Viscous Heater:  
Inspect power heater indicator operation.  
Connect the positive (+) lead from the battery to terminal 5 and negative (-) lead to terminal 6 then check that the indicator lights up.

If operation is not as specified, check the bulb.



- (c) Inspect the idle-up switch continuity.  
Check the continuity exists between terminals 3 and 4.  
If no continuity exists, replace the switch.

#### 3. INSTALL IDLE-UP SWITCH