

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	A45	ABS Speed Sensor Rear LH (Independent Suspension)	90980-11073
A 2	A/C Condenser Fan Motor	90980-11237		ABS Speed Sensor Rear LH (Rigid Axle Suspension)	90980-11075
A 4	Pressure SW (w/ Rear A/C)	90980-10943		A46	ABS Speed Sensor Rear RH (Independent Suspension)
	Pressure SW (w/o Rear A/C)	90980-11149	ABS Speed Sensor Rear RH (Rigid Axle Suspension)		90980-11075
A 5	A/C Magnetic Clutch	90980-11271	A47		Accumulator Solenoid
A 6	A/C Magnetic Clutch and Lock Sensor	90980-11016	A48	ABS & BA & TRC & VSC Actuator	90980-11413
A 7	A/C Magnetic Valve	90980-11075	A49	ABS & BA & TRC & VSC Actuator	90980-10895
A 9	A/T Oil Temp. Sensor	90980-11243	A50	ABS & BA & TRC & VSC Actuator	90980-11151
A10	ABS Actuator	90980-11413	A51	ABS & BA & TRC & VSC Actuator	90980-11009
A11	ABS Actuator	90980-10895	A52	ABS & BA & TRC & VSC ECU	90980-11935
A12	ABS Actuator	90980-11151	A53	ABS & BA & TRC & VSC ECU	90980-11476
A13	ABS Actuator	90980-11009	A54	ABS & BA & TRC & VSC ECU	90980-11637
A15	ABS Speed Sensor Front LH	90980-10941	A55	ABS & BA & TRC & VSC ECU	90980-11638
A16	ABS Speed Sensor Front RH	90980-11002	A56	ADD Control Motor	90980-11024
A17	Accel Position Sensor (1HD-FTE)	90980-11232	A57	A/C Control Assembly	90980-12170
	Accel Position Sensor (2UZ-FE)	90980-11144	A58	A/C Control Assembly	90980-11913
A18	AHC Pump Motor	90980-10928	A59	A/C Control Assembly	90980-11927
A19	Air Cleaner Warning Sensor	90980-11025	A60	A/T Shift Lever Illumination	90980-11911
A20	Air Flow Meter	90980-11317		Shift Lock Control ECU	
A21	Airbag Sensor Front LH	90980-11856	A61	ADD Control Relay	90980-10801
A22	Airbag Sensor Front RH		A62	Airbag Sensor Assembly (w/ Side Airbag)	82824-50150
A23	Alternator (1HZ, 1HD-FTE)	90980-09213		Airbag Sensor Assembly (w/o Side Airbag)	90980-11871
	Alternator (2UZ-FE, 1FZ-FE)	90980-09212	A63	Airbag Sensor Assembly (w/ Side Airbag)	82824-50160
A24	Alternator	90980-11349		Airbag Sensor Assembly (w/o Side Airbag)	90980-11873
A25	Auto Antenna Motor	90980-11194	A64	Auto Wiper ECU	90980-10801
A26	A/C Solar Sensor	90980-11919		Short Connector	
A27	A/C Thermistor	90980-11918	A65	Auto Wiper ECU	90980-12183
A28	ABS Deceleration Sensor	90980-10845	A66	Automatic Light Control Sensor	90980-12056
A29	ABS ECU	90980-11424	A67	Airbag Sensor Assembly	90980-11872
A30	ABS ECU	90980-11391	B 1	Back-Up Light SW (Except 1HZ)	90980-11051
A31	ABS ECU	90980-11390		Back-Up Light SW (1HZ)	90980-11250
A32	Accelerator Pedal SW	90980-10825	B 2	Brake Fluid Level Warning SW	90980-11207
A33	AHC Main Relay	90980-10171	B 3	Blower Motor Controller (LHD, RHD Europe)	90980-10910
A34	Air Inlet Control Servo Motor	90980-11909		Blower Motor Controller (RHD Except Europe)	90980-11667
A35	Air Mix Control Servo Motor (LHD)	90980-10797	B 4	Blower HI Relay	90980-10713
	Air Mix Control Servo Motor (RHD)	90980-11529	B 5	Blower LO Relay	90980-10171
A36	Air Vent Mode Control Servo Motor (LHD)	90980-11165	B 6	Blower ME Relay	
	Air Vent Mode Control Servo Motor (RHD)	90980-11321	B 7	Back Door Courtesy SW (Liftgate Type)	90980-10039
A37	Airbag Squib (Front Passenger Airbag Assembly)	90980-12160		Back Door Courtesy SW (Swing Type)	90980-11367
A38	Airbag Squib (Steering Wheel Pad)		B 8	Back Door Key Lock and Unlock SW (Liftgate Type)	90980-11490
A39	Ashtray Illumination	90980-10825		Back Door Key Lock and Unlock SW (Swing Type)	90980-11169
A40	Auto Antenna Control Relay	90980-10819			
A41	A/C Amplifier	90980-11497			
A42	A/C Amplifier	90980-11475			
A43	A/C Amplifier	90980-11502			
A44	A/C Amplifier	90980-10801			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
B 9	Back Door Lock Motor and Back Door Unlock Detection SW	90980-11150	D10	Damping Force Control Actuator Front LH	90980-11960
B10	Buckle SW LH	90980-11169	D11	Damping Force Control Actuator Front RH	
B11	Buckle SW RH		D12	Damping Force Control Actuator Rear LH	
B12	Body ECU	90980-12151	D13	Damping Force Control Actuator Rear RH	
B13	Body ECU	90980-12149	D14	Detection SW (Rear Diff. Lock) (Independent Suspension)	90980-11156
B14	Body ECU	90980-12150		Detection SW (Rear Diff. Lock) (Rigid Axle Suspension)	90980-11250
B15	Buckle SW LH	90980-11599	D15	Door Courtesy Light Front LH	90980-11148
	Seat Position Sensor		D16	Door Courtesy Light Front RH	
B16	Buckle SW RH		D17	Door Courtesy Light Rear LH	
	Seat Position Sensor		D18	Door Courtesy Light Rear RH	
C 1	Camshaft Position Sensor	90980-10947	D19	Door Courtesy SW Front LH	90980-10871
C 2	Center Diff. Lock Control Motor	90980-11024	D20	Door Courtesy SW Front RH	
C 3	Check Connector	90980-11195	D21	Door Courtesy SW Rear LH	
C 4	Crankshaft Position Sensor (1FZ-FE)	90980-11016	D22	Door Courtesy SW Rear RH	
	Crankshaft Position Sensor (1HD-FTE)	90980-11162	D23	Door Key Lock and Unlock SW LH	90980-11170
	Crankshaft Position Sensor (2UZ-FE)		D24	Door Key Lock and Unlock SW RH	
C 6	CD Automatic Changer (LHD)	90980-10803	D25	Door Lock Motor Front LH	90980-11150
	CD Automatic Changer (RHD)	90980-12200		Door Unlock Detection SW Front LH	
C 8	Center Diff. Lock Control Relay	90980-10801	D26	Door Lock Motor Front RH	
C13	Cigarette Lighter	90980-10760		Door Unlock Detection SW Front RH	
C14	Cigarette Lighter Illumination	90980-11148	D27	Door Lock Motor Rear LH	
C15	Combination Meter	82824-60060		Door Unlock Detection SW Rear LH	
C16	Combination Meter	82824-60050	D28	Door Lock Motor Rear RH	
C17	Combination Meter	82824-60060		Door Unlock Detection SW Rear RH	
C18	Combination Meter	82824-60050	D29	Driving Position Memory SW	90980-10601
C19	Combination SW (LHD, RHD Europe)	90980-11672	D30	Detection SW (Front Diff. Lock)	90980-11250
	Combination SW (RHD Except Europe)	90980-11671	D32	Diesel Throttle Position SW	90980-11038
C20	Combination SW	90980-12155	D33	Deceleration Sensor	90980-12080
C22	Combination SW	90980-11594	D34	Diode (Front Fog No.2)	90980-10637
C23	Cooler Box	90980-11535	D35	Diode (Viscous Heater1)	
C24	Cruise Control Clutch SW	90980-10906	D36	Diode (Viscous Heater2)	
C26	Control Valve Assembly	90980-11599	D37	Double Lock Control Relay	90980-10807
C32	Center Cluster Integration Panel	90980-12200	D38	Door Control Receiver	90980-11909
C33	Combination SW	90980-12183	D39	Door Lock Motor Front LH	90980-10890
C35	Curtain Shield Airbag Squib LH	90980-11864		Door Unlock Detection SW Front LH	
C36	Curtain Shield Airbag Squib RH			Double Lock Motor Front LH	
D 1	Detection SW (Center Diff. Lock)	90980-11250		Double Lock Position SW Front LH	
D 2	Detection SW (Transfer L Position)		D40	Door Lock Motor Front RH	
D 3	Detection SW (Transfer Neutral Position)	90980-11025		Door Unlock Detection SW Front RH	
D 4	Diesel Engine Revolution Sensor	90980-11250		Double Lock Motor Front RH	
D 5	Damping Mode Select SW and Height Control SW	90980-11533		Double Lock Position SW Front RH	
D 7	Diode (Front Fog No.1)	90980-10637	D41	Door Lock Motor Rear LH	90980-10891
D 8	DLC3	90980-11665		Door Unlock Detection SW Rear LH	
D 9	Door Lock Control SW (LHD)	90980-10797		Double Lock Motor Rear LH	
	Door Lock Control SW (RHD)	90980-10996		Double Lock Position SW Rear LH	

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
D42	Door Lock Motor Rear RH	90980-10891	E19	Engine and ECT ECU (1HD-FTE Europe)	90980-11392
	Door Unlock Detection SW Rear RH			Engine and ECT ECU (1HD-FTE Except Europe)	90980-12142
	Double Lock Motor Rear RH			Engine ECU (1HD-FTE Europe)	90980-11392
	Double Lock Position SW Rear RH			Engine ECU (1HD-FTE Except Europe)	90980-12142
E 1	ECT Solenoid (1FZ-FE)	90980-10854	E20	Engine and ECT ECU	90980-11129
	ECT Solenoid (1HD-FTE Europe)	90980-10891		Engine ECU	
	ECT Solenoid (2UZ-FE, 1HD-FTE Except Europe)	90980-12293	E21	Emission Control ECU	90980-11390
E 2	EFI Water Temp. Sensor (1FZ-FE, 1HD-FTE)	90980-10737	E22	Emission Control ECU	90980-11391
	EFI Water Temp. Sensor (2UZ-FE)	90980-10736	F 1	First Position SW	90980-10923
E 3	Engine Hood Courtesy SW	90980-11003	F 2	Fluid Pressure Sensor	90980-11451
E 4	ECT ECU	90980-11424	F 3	Front Clearance Light LH	90980-11156
E 5	ECT ECU	90980-11392	F 4	Front Clearance Light RH	
E 6	ECT Pattern Select SW	90980-10933	F 5	Front Fog Light LH	90980-11660
E 7	Engine and ECT ECU	90980-12144	F 6	Front Fog Light RH	
	Engine ECU		F 7	Front Side Turn Signal Light LH	90980-11162
E 8	Engine and ECT ECU	90980-12145	F 8	Front Side Turn Signal Light RH	
	Engine ECU		F 9	Front Turn Signal Light LH	90980-11019
E 9	Engine and ECT ECU	90980-12143	F10	Front Turn Signal Light RH	
	Engine ECU		F11	Front Wiper Motor	90980-11599
E10	Engine and ECT ECU	90980-12146	F12	Fuel Cut Valve Controller	90980-11349
	Engine ECU		F13	Fuel Heater SW	90980-10928
E11	Engine and ECT ECU	90980-12142	F14	Fuel Pump Resistor	90980-11156
	Engine ECU		F15	Fuel Sediment SW	90980-11003
E12	Engine and ECT ECU	90980-11391	F16	Fuel Temp. Sensor	90980-10737
	Engine ECU		F17	Fusible Link Block	82675-60050
E13	Engine and ECT ECU	90980-11390	F19	Front Blower Motor	90980-10903
	Engine ECU		F20	Front Blower Resistor (LHD)	90980-10910
E14	Engine and ECT ECU	90980-11392			Front Blower Resistor (RHD)
	Engine ECU		F21	Front/Rear Diff. Lock Control SW	90980-10631
E15	EDU	90980-11024	F22	Fuel Tank Changeover SW	90980-10933
E16	Engine and ECT ECU (1HD-FTE Europe)	90980-11391	F23	Front Door Speaker LH	90980-10935
	Engine and ECT ECU (1HD-FTE Except Europe)	90980-12144	F24	Front Door Speaker RH	
	Engine ECU (1HD-FTE Europe)	90980-11391	F25	Front Interior Light	
	Engine ECU (1HD-FTE Except Europe)	90980-12144	F26	Front Personal Light	90980-10825
E17	Engine and ECT ECU (1HD-FTE Europe)	90980-11390	F27	Front/Rear Diff. Lock Control ECU	90980-10848
	Engine and ECT ECU (1HD-FTE Except Europe)	90980-12145	F28	Fuel Pump	90980-11077
	Engine ECU (1HD-FTE Europe)	90980-11390		Fuel Sender	
	Engine ECU (1HD-FTE Except Europe)	90980-12145	F30	Fuel Pump Select Relay	90980-10173
E18	Engine and ECT ECU (1HD-FTE Europe)	90980-11408	F31	Fuel Solenoid Valve 1	90980-10901
	Engine and ECT ECU (1HD-FTE Except Europe)	90980-12146	F32	Fuel Solenoid Valve 2	
	Engine ECU (1HD-FTE Europe)	90980-11408	F33	Front Diff. Lock Motor	90980-11290
	Engine ECU (1HD-FTE Except Europe)	90980-12146	F35	Fuel Pump Resistor LH	90980-11156
		F36	Fuel Pump Resistor RH		
			F37	Fusible Link Block	90980-11996

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
F38	Fusible Link Block	90980-11881	I13	Injector No.4	90980-11153
F39	Fusible Link Block	90980-11775	I14	Injector No.5	
F40	Fusible Link Block	90980-10995	I15	Injector No.6	
G 1	Glow Plug	99141-13004	I16	Injector No.7	
G 2	Glow Plug Relay	90980-11569	I17	Injector No.8	
G 3	Glove Box Light	90980-11098	I18	Intake Air Temp. Sensor (1FZ-FE)	90980-11163
G 4	Gateway ECU	90980-11911		Intake Air Temp. Sensor (1HD-FTE)	90980-11025
H 1	Headlight Beam Level Control Actuator LH	90980-11016	I19	Intake Heater	99141-14006
H 2	Headlight Beam Level Control Actuator RH		I20	Intake Heater Relay	90980-11248
H 3	Headlight Cleaner Control Relay	90980-10939	I21	Intake Heater Relay	99141-14006
H 4	Headlight Cleaner Motor	90980-11410	I22	Intake Heater Relay	
H 5	Headlight Control ECU LH	90980-11255	I23	ISC Valve	90980-11145
H 6	Headlight Control ECU RH		I24	Idle-Up SW	90980-10933
H 7	Headlight LH (High)	90980-11659	I26	Ignition SW	90980-11615
H 8	Headlight RH (High)		I30	Inner Mirror	90980-11186
H 9	Headlight LH (Low)	90980-11660	J 1	Junction Connector	90980-11915
H10	Headlight RH (Low)		J 2	Junction Connector	
H11	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869	J 3	Junction Connector	
H12	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028	J 4	Junction Connector	
H13	Heated Oxygen Sensor (Bank 2 Sensor 1)	90980-10869	J 5	Junction Connector	90980-11398
H14	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11028	J 6	Junction Connector	90980-11927
H15	Height Control Sensor Front LH	90980-11015	J 7	Junction Connector	
H16	Height Control Sensor Front RH		J 8	Junction Connector	90980-11661
H17	Horn LH	90980-10619	J 9	Junction Connector	
H18	Horn RH		J10	Junction Connector	
H19	Headlight Beam Level Control SW	90980-10996	J11	Junction Connector	
H20	Height Control Sensor Rear	90980-11143	J12	Junction Connector	90980-10803
H21	High Mounted Stop Light (Liftgate Type)	90980-11211	J13	Junction Connector	
	High Mounted Stop Light (Swing Type)	90980-10825	J14	Junction Connector	90980-11398
H22	Heated Oxygen Sensor	90980-11028	J15	Junction Connector	
H23	Headlight Cleaner SW	90980-12063	J16	Junction Connector	
I 1	Ignition Coil and Igniter No.1 (1FZ-FE)	90980-11150	J17	Junction Connector	
	Ignition Coil and Igniter No.1 (2UZ-FE)	90980-11885	J18	Junction Connector	
I 2	Ignition Coil and Igniter No.2 (1FZ-FE)	90980-11150	J19	Junction Connector	
	Ignition Coil and Igniter No.2 (2UZ-FE)	90980-11885	J20	Junction Connector	90980-11927
I 3	Ignition Coil and Igniter No.3 (1FZ-FE)	90980-11150	J21	Junction Connector	90980-11742
	Ignition Coil and Igniter No.3 (2UZ-FE)	90980-11885	J22	Junction Connector	
I 4	Ignition Coil and Igniter No.4	90980-11885	J24	Junction Connector	90980-11927
I 5	Ignition Coil and Igniter No.5		J25	Junction Connector	
I 6	Ignition Coil and Igniter No.6		J26	Junction Connector	
I 7	Ignition Coil and Igniter No.7		J27	Junction Connector	
I 8	Ignition Coil and Igniter No.8		J28	Junction Connector	90980-11925
I 9	Injection Pump	90980-11028	J29	Junction Connector	
I10	Injector No.1	90980-11153	J30	Junction Connector	90980-11915
I11	Injector No.2		J31	Junction Connector	
I12	Injector No.3		J32	Junction Connector	

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
K 1	Knock Sensor 1	90980-11166	P17	Power Window Motor Front LH	90980-11599
K 2	Knock Sensor 2		P18	Power Window Motor Front RH	
L 1	License Plate Light	90980-11159	P19	Power Window Motor Rear LH	
L 2	License Plate Light LH	90980-11148	P20	Power Window Motor Rear RH	
L 3	License Plate Light RH		P21	Pretensioner LH	90980-11862
L 4	Lumbar Support Control SW (Driver's Seat)	90980-10601	P22	Pretensioner RH	
L 5	License Plate Light No.1	90980-11159	P23	Power Seat Control SW (Driver's Seat) (w/ Driving Position Memory)	90980-11909
L 6	License Plate Light No.2	90980-10871		Power Seat Control SW (Driver's Seat) (w/o Driving Position Memory)	90980-10803
M 1	Moon Roof Control ECU	90980-10997	P24	Power Seat Control SW (Front Passenger's Seat)	90980-10803
M 2	Moon Roof Control SW	90980-10789			
M 3	Master Cylinder Pressure Sensor	90980-11451	P27	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825
M 4	Multi-Display (w/ Navigation System)	90980-11911	P28	Power Seat Motor (Driver's Seat Lumbar Support Control)	
	Multi-Display (w/o Navigation System)	90980-12094	P29	Power Seat Motor (Driver's Seat Rear Vertical Control)	
M 5	Multi-Display	90980-11923	P30	Power Seat Motor (Driver's Seat Reclining Control)	
N 1	A/T Indicator Light SW (1HD-FTE 4AT, 1FZ-FE LHD)	90980-11332	P31	Power Seat Motor (Driver's Seat Slide Control)	
	A/T Indicator Light SW (2UZ-FE, 1HD-FTE 5A/T)	90980-11784	P32	Power Seat Motor (Front Passenger's Seat Front Vertical Control)	
	Neutral Start SW (1HD-FTE 4AT, 1FZ-FE LHD)	90980-11332	P33	Power Seat Motor (Front Passenger's Seat Rear Vertical Control)	
	Neutral Start SW (2UZ-FE, 1HD-FTE 5A/T)	90980-11784	P34	Power Seat Motor (Front Passenger's Seat Reclining Control)	
N 2	Noise Filter (Ignition)	90980-10843	P35	Power Seat Motor (Front Passenger's Seat Slide Control)	
N 4	Navigation ECU	90980-11973	R 2	Radio and Player	90980-10997
N 5	Navigation ECU	90980-11923	R 3	Radio and Player	90980-10803
N 6	Noise Filter (ABS)	90980-10983	R 4	Radio and Player	90980-10996
N 7	Navigation ECU	90980-12221	R 6	Rear Diff. Lock Control ECU	90980-10801
O 2	O/D Main SW	90980-11606	R 7	Rear Fog Light SW	90980-12113
O 3	Oil Level Sensor (1FZ-FE)	90980-11235	R 9	Remote Control Mirror SW	90980-11657
	Oil Level Sensor (1HZ, 1HD-FTE)	90980-10532	R10	Remote Control Mirror SW	90980-11319
	Oil Level Sensor (2UZ-FE)		R11	Rheostat (Except Optitron Meter)	90980-10908
O 4	Oil Pressure Sender (1HZ, 1HD-FTE)	90980-10703		Rheostat (Optitron Meter)	90980-10799
	Oil Pressure Sender (2UZ-FE, 1FZ-FE)	90980-11363	R12	Room Temp. Sensor (Front)	90980-11918
O 5	Overhead J/B	90980-11909	R13	Rear A/C Control SW (Rear Automatic A/C)	90980-11503
O 6	Overhead J/B	90980-12155		Rear A/C Control SW (Rear Manual A/C)	90980-10878
P 1	Pick-Up Sensor	90980-11157	R14	Rear Air Mix Control Servo Motor	90980-11319
P 2	Power Steering Oil Pressure SW	90980-11428	R15	Rear Combination Light LH	90980-11587
P 3	Power Outlet (Front)	90980-10760	R16	Rear Combination Light LH (w/ Rear Fog Light)	90980-10825
P 6	Pre-Heating Timer	90980-10803		Rear Combination Light LH (w/ Rear Fog Light)	90980-10908
P 7	Parking Brake SW	90980-10871	R17	Rear Combination Light RH	90980-11587
P 8	Power Outlet (Luggage Compartment)	90980-10860			
P11	Power Window Control SW Front LH	90980-11947			
P12	Power Window Control SW Front RH				
P13	Power Window Control SW Rear LH				
P14	Power Window Control SW Rear RH				
P15	Power Window Master SW	90980-12166			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
R18	Rear Combination Light RH (w/ Rear Fog Light)	90980-10825	R61	Roll Sensing of Curtain Shield Airbags Cutoff SW	90980-10957
	Rear Combination Light RH (w/ Rear Fog Light)	90980-10908	S 1	Speed Sensor (Combination Meter)	90980-11143
R19	Rear Cooler Blower Motor	90980-10214	S 2	Speed Sensor (ECT)	90980-11156
R20	Rear Cooler Magnetic Valve	90980-10860	S 3	Spill Valve	90980-11155
R21	Rear Cooler Power Transistor	90980-10171	S 4	Starter (1FZ-FE)	90980-09506
R22	Rear Cooler Relay	90980-10175		Starter (1HZ,1HD-FTE)	90980-09508
R23	Rear Diff. Lock Motor (Independent Suspension)	90980-11194		Starter (2UZ-FE)	90980-09585
	Rear Diff. Lock Motor (Rigid Axle Suspension)	90980-11290	S 5	Starter (1HZ, 1HD-FTE)	90980-11184
R24	Rear Door Speaker LH	90980-10935		Starter (2UZ-FE, 1FZ-FE)	90980-11400
R25	Rear Door Speaker RH		S 6	Stop Light SW	90980-11118
R26	Rear Evaporator Temp. Sensor	90980-11918	S 7	Suspension Control ECU	90980-11424
R27	Rear Heater Blower Motor	90980-10860	S 8	Suspension Control ECU	90980-11391
R28	Rear Heater Blower Resistor	90980-10916	S 9	Suspension Control ECU	90980-11390
R29	Rear Heater Control SW	90980-10797	S10	Seat Heater SW (Driver's Seat) (LHD)	90980-10797
R30	Rear Heater Power Transistor	90980-10171		Seat Heater SW (Driver's Seat) (RHD)	90980-10996
R31	Rear Heater Relay		S11	Seat Heater SW (Front Passenger's Seat) (LHD)	90980-10996
R32	Rear Inlet Air Temp. Sensor	90980-11369		Seat Heater SW (Front Passenger's Seat) (RHD)	90980-10797
R33	Rear Interior Light	90980-10935	S14	Sub Fuel Pump	90980-11038
R34	Rear Personal Light (w/ Moon Roof)	90980-12211	S15	Sub Fuel Pump Forcing Driving Relay	90980-10171
	Rear Personal Light (w/o Moon Roof)	90980-10365	S16	Sub Fuel Sender	90980-11016
R35	Rear Window Defogger	90980-11097	S17	Seat Belt Warning Occupant Detection Sensor	90980-10860
R36	Rear Window Defogger		S18	Seat Heater (Driver's Seat)	90980-10907
R37	Rear Window Defogger LH	90980-10792	S19	Seat Heater (Front Passenger's Seat)	
R38	Rear Window Defogger LH		S20	Swirl Control Valve	90980-11156
R39	Rear Window Defogger RH		S21	Side Airbag Sensor Front LH	90980-12225
R40	Rear Window Defogger RH		S22	Side Airbag Sensor Front RH	
R41	Rear Wiper Motor	90980-10795	S23	Side Airbag Sensor Rear LH	
R42	Rear Wiper Motor LH		S24	Side Airbag Sensor Rear RH	
R43	Rear Wiper Motor RH		S25	Stereo Component Amplifier	90980-10848
R44	Rear Wiper Relay (Liftgate Type)	90980-10797	S26	Stereo Component Amplifier	90980-11877
	Rear Wiper Relay (Swing Type)	90980-10801	S27	Seat Heater (Driver's Seat Cushion)	90980-10794
R47	Remote Control Mirror ECU	90980-11877	S28	Seat Heater (Front Passenger's Seat Cusion)	
R48	Remote Control Mirror LH	90980-11573	S29	Seat Position Sensor	90980-12195
R49	Remote Control Mirror RH		S30	Side Airbag Squib LH	90980-11864
R50	Room Temp. Sensor (Rear)	90980-11918	S31	Side Airbag Squib RH	
R53	Radio and Player	90980-12038	S32	Seat ECU	90980-10801
R54	Radio and Player	90980-12259	T 1	Temp. Sensor (AHC)	90980-10737
R55	Radio and Player	90980-12183	T 2	Theft Deterrent Horn	90980-10619
R56	Rear Diff. Lock Control SW	90980-10631	T 3	Throttle Control Motor	90980-11144
R57	Rear Seat Audio Controller	90980-12200	T 4	Throttle Position Sensor	90980-11261
R58	Rain Sensor	90980-12263	T 5	Timing Control Valve	90980-11285
R59	Rear Cooler Blower Resistor	90980-10171	T 6	Turbo Pressure Sensor	90980-10845
R60	Rear Fog Light	90980-10860			

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
T 8	Telescopic Motor	90980-10799	W11	Winch Motor and Magnetic SW	90980-09552
T 9	Theft Deterrent ECU	90980-12169	W13	Woofer (Speaker)	90980-10795
T11	Tilt and Telescopic ECU	90980-10799	Z 1	Option Connector (Glass Breakage Sensor)	90980-10799
T12	Tilt and Telescopic ECU	90980-10848	Z 2	Option Connector (Hand Set)	90980-10798
T13	Tilt Motor	90980-10799	Z 3	Option Connector (Radar Sensor)	90980-11013
T14	Ignition Key Cylinder Light	90980-12092	Z 4	Option Connector (Celular Mobile Telephone)	90980-11910
	Transponder Key Amplifier		Z 5	Option Connector (Celular Mobile Telephone)	90980-11912
T15	Transponder Key Computer (1HZ)	90980-12183	Z 6	Option Connector (Celular Mobile Telephone)	90980-11001
	Transponder Key Computer (2UZ-FE, 1FZ-FE, 1HD-FTE)	90980-11911	Z 7	Option Connector (Celular Mobile Telephone)	90980-10998
T16	Turn Signal Flasher	90980-10799	Z 8	Option Connector (Microphone)	90980-11368
T17	Tire Carrier Courtesy SW	90980-10870	Z 9	Option Connector (Trailer Towing)	90980-10988
T19	Tweeter LH	90980-11300	Z10	Option Connector (Wireless Door Lock Buzzer)	90980-11051
T20	Tweeter RH				
T22	TVSS ECU	90980-10803			
T23	Throttle Control Motor and Sensor	90980-11858			
T24	Throttle Position Sensor and Timing Control Valve	90980-11599			
T25	Turbine Speed Sensor	90980-11156			
T26	Theft Deterrent Siren	90980-11349			
U 1	Unlock Warning SW	90980-10860			
V 1	Vacuum Sensor	90980-10845			
V 2	Vacuum SW	90980-11252			
V 3	Variable Resistor	90980-10902			
V 4	Viscous Heater Magnetic Clutch	90980-11271			
V 6	VRV (EGR)	90980-11162			
V 7	VSV (A/C Idle-UP)	90980-11156			
V 8	VSV (EGR Cut)	90980-11149			
V 9	VSV (EVAP)	90980-11156			
V10	VSV (Fully Closed)				
V11	VSV (Turbo Pressure Sensor)				
V12	Viscous Heater Amplifier	90980-10801			
V13	VSC Warning Buzzer	90980-10906			
V14	VRV (EGR No.2)	90980-11162			
V15	VSV (BACS)	90980-10572			
V16	VGRS ECU	90980-12120			
V17	VGRS ECU	90980-11915			
V18	Vanity Light LH	90980-11186			
V19	Vanity Light RH				
W 2	Washer Motor	90980-11294			
W 3	Water Temp. Sender	90980-11428			
W 4	Water Temp. Sensor (Glow Plug)	90980-10737			
W 5	Water Temp. SW (A/C)	90980-10184			
W 7	Winch Main Relay	90980-10887			
W 8	Winch Main Relay	-			
W 9	Winch Main Relay				
W10	Winch Motor and Magnetic SW	90980-10887			

Note: Not all of the above part numbers of the connector are established for the supply.

