

## Abnormal noise and vibration in the steering wheel

### INSPECTION PROCEDURE

Check that the DTCs of VGRS, VSC and ABS are normal.

1	<b>Check for abnormal noise and vibration when turning the steering wheel.</b>
---	--

#### PREPARATION:

- (a) Turn the ignition switch OFF.
- (b) Disconnect the VGRS actuator connector from VGRS ECU.

#### CHECK:

Check for abnormal noise and vibration, after starting the engine and turning the steering wheel.

#### OK:

**No abnormal noise and vibration**

#### **NOTICE:**

**When the ignition switch is ON with the steering actuator connector disconnected, DTC C1561/61 is stored. Clear this code after this check.**

**NG**

**Check and repair power steering system.**

**OK**

**Replace VGRS actuator.**