

## PRECAUTION

### NOTICE:

Perform the RESET MEMORY (AT initialization) when replacing the automatic transmission assy, engine assy or the ECM (See page DI-5).

### HINT:

Initialization can not be completed by only disconnecting the battery terminal.

