

Power Source

Headlight (w/ Daytime Running Light)

The diagram illustrates the electrical system for the power source and headlight. Key components and connections include:

- Power Source:**
 - BATTERY:** Connected to the ground (EE) and the main power line.
 - F-17 FUSIBLE LINK BLOCK:** Contains fuses for 100A MAIN, 100A J/B NO. 2, and 140A ALT.
 - IG1 NO. 1 RELAY:** Controls the ignition system.
 - IG1 NO. 2 RELAY:** Controls the ignition system.
 - AM1 NO. 1 and AM1 NO. 2:** Additional relays or components in the ignition circuit.
- Headlight (w/ Daytime Running Light):**
 - D 6 DAYTIME RUNNING LIGHT RELAY:** Controls the daytime running lights.
 - 15A GAUGE:** Monitors the system voltage.
 - 15A ECU-B:** Controls the ECU (Engine Control Unit).
 - Wiring Labels:** B, B-R, L-B, R-L, R-W, T, CHG, H-LP, TAIL, and others.

Notes and additional information:


- EE:** Front left side of fender apron.
- ACC:** Accessory power source.
- J15 JUNCTION CONNECTOR:** Connects the ignition switch to the relay.
- From Alternator <249-3> <253-3>:** Indicates the power source for the daytime running light relay.
- See Taillight System <334-2>:** Refers to the taillight system for further details.

* Z : TAD-FTE



F ELECTRICAL WIRING DIAGRAM (System Circuits)

Headlight (w/ Daytime Running Light)



A horizontal number line with arrows at both ends. There are four major tick marks labeled 6, 7, 8, and 9 from left to right. The tick mark for 7 is located at the midpoint between 6 and 8.

