

The diagram is divided into two main sections: **Power Source** and **Key Reminder and Seat Belt Warning**.

Power Source Section:

- BATTERY:** Connected to the **Front left side of fender apron** (EE).
- F17 FUSIBLE LINK BLOCK:** Contains a 100A J/B NO. 2 and a 140A ALT.
- IGNITION SW (I26):** Includes an AM1 switch and an ACC terminal.
- RELAYS:**
 - IG1 NO. 1 RELAY:** Controls the **15A GAUGE** (2P, 2H) and the **SEAT BELT** warning light.
 - IG1 NO. 2 RELAY:** Controls the **SEAT BELT** warning light.
- FUSES:** 20A A.C. and 80A AM1 NO. 1.

Key Reminder and Seat Belt Warning Section:

- SEAT BELT:** A sensor that triggers the **SEAT BELT** warning light.
- BUCKLE SW RH (B11):** A switch located at the **Front side under the front seat RH** (BK).
- WARNING LIGHTS:**
 - Key Reminder:** Indicated by a key symbol and a warning light.
 - Seat Belt Warning:** Indicated by a seat belt symbol and a warning light.
- Wiring Connections:** Various wires (B, R-L, L-B, SB, BR, W-B) connect the components to the battery and ground.

