


## ECT ECU Power Source Circuit

## CIRCUIT DESCRIPTION


Battery positive voltage is supplied to terminal +B of the ECT ECU even when the ignition switch is OFF for use by the DTC memory.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check voltage between terminal +B and GND of ECT ECU connector.

**PREPARATION:**

- (a) Remove the glove compartment door (See page BO-127).
- (b) Check voltage between terminal +B and GND of ECT ECU.

**CHECK:**

Check voltage between terminal +B and GND of ECT ECU.

**OK:**


9.0 – 14 V

OK

Check and replace ECT ECU (See page IN-35).

NG

## 2 Check ECU-B fuse.

**PREPARATION:**

Remove the ECU-B fuse.

**CHECK:**

Check continuity of ECU-B fuse.

**OK:**

Continuity

NG

Check for short in all harness and components connected to ECU-B fuse.

OK

Check and repair harness or connector between battery, ECU-B fuse and ECT ECU (See page IN-35).