

REMOVAL

REMOVE INTAKE MANIFOLD WITH INTAKE AIR CONTROL VALVE  
(See page EM-23)