



- B 11 Buckle SW RH
- B 15 Buckle SW LH , Seat Position Sensor

- P 24 Power Seat Control SW (Front Passenger's Seat)
- P 32 Power Seat Motor (Front Passenger's Seat Front Vertical Control)
- P 33 Power Seat Motor (Front Passenger's Seat Rear Vertical Control)
- P 34 Power Seat Motor (Front Passenger's Seat Reclining Control)
- P 35 Power Seat Motor (Front Passenger's Seat Slide Control)

- S 17 Seat Belt Warning Occupant Detection Sensor
- S 19 Seat Heater (Front Passenger's Seat)
- S 28 Seat Heater (Front Passenger's Seat Cushion)
- S 30 Side Airbag Squib LH
- S 31 Side Airbag Squib RH
- S 32 Seat ECU

Position of Parts in Seat <LHD w/ Driving Position Memory>

B 11
Gray (LHD w/ Seat Heater)



B 11
White (LHD w/o Seat Heater, RHD w/o Driving Position Memory)

