


Open door warning light circuit

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:
In case of using the hand-held tester, start the inspection from step 1 and in case of not using the hand-held tester, start from step 2.

1	Check open door warning light using hand-held tester.
---	---

PREPARATION:
Connect the hand-held tester to DLC3.

CHECK:
Check that the open door warning light operate in ACTIVE TEST (See page DI-981).

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-992).

NG

2 Check the combination meter circuit ([See page BE-41](#)).

NG

Replace the combination meter.

OK

3 Check wire harness and connector between combination meter and Body ECU ([See page IN-38](#)).

NG

Repair or replace wire harness or connector.

OK

Proceed to next circuit inspection shown on problem symptoms table ([See page DI-992](#)).