

Position of Parts in Engine Compartment

Code	English	Deutsch
H 3	Headlight Cleaner Control Relay	Scheinwerferwaschersteuerrelais
H 4	Headlight Cleaner Motor	Scheinwerferwaschermotor
H 7	Headlight LH (High)	Scheinwerfer, links (Fern)
H 8	Headlight RH (High)	Scheinwerfer, rechts (Fern)
H 9	Headlight LH (Low)	Scheinwerfer, links (Abblend)
H 10	Headlight RH (Low)	Scheinwerfer, rechts (Abblend)
H 15	Height Control Sensor Front LH	Höhensteuerungssensor, vorne, links
H 16	Height Control Sensor Front RH	Höhensteuerungssensor, vorne, rechts
H 17	Horn LH	Hupe, links
H 18	Horn RH	Hupe, rechts
N 1	Neutral Start SW, A/T Indicator Light SW and Back-Up Light SW	Neutralstartschalter, A/T-Fahrstufenanzeige und Rückfahrscheinwerferschalter
O 4	Oil Pressure Sender	Öldruckgeber
P 1	Pick-Up Sensor	Drehzahlsensor
S 1	Speed Sensor (Combination Meter)	Geschwindigkeitssensor (Kombiinstrument)
S 2	Speed Sensor (ECT)	Geschwindigkeitssensor (ECT)
S 4	Starter	Anlasser
S 5	Starter	Anlasser
T 1	Temp. Sensor (AHC)	Temperatursensor (AHC)
T 2	Theft Deterrent Horn	Diebstahlschutzhupe
T 7	Turbo Pressure SW	Ladedruckschalter
V 2	Vacuum SW	Unterdruckschalter
V 7	VSV (A/C Idle-Up)	VSV (A/C-Schnelleerlauf)
W 1	Water Temp. Cut Relay	Kühlmitteltemperatur-Abschaltrelais
W 2	Washer Motor	Waschermotor
W 3	Water Temp. Sender	Kühlmitteltemperaturgeber
W 4	Water Temp. Sensor (Glow Plug)	Kühlmitteltemperatursensor (Glühkerzen)
W 5	Water Temp. SW (A/C)	Kühlmitteltemperaturschalter (A/C)
W 6	Water Temp. SW (ECT)	Kühlmitteltemperaturschalter (ECT)
W 7	Winch Main Relay	Windenhauptrelais
W 8	Winch Main Relay	Windenhauptrelais
W 9	Winch Main Relay	Windenhauptrelais
W 10	Winch Motor and Magnetic SW	Windenmotor und Magnetschalter
W 11	Winch Motor and Magnetic SW	Windenmotor und Magnetschalter