

INSTALLATION

Installation is in the reverse order of removal (See page TR-5).

HINT:

- Apply MP grease to the transfer adaptor oil seal.
- After install, do the road test.