

CIRCUIT INSPECTION

DTC	P0500/21,23	Vehicle Speed Sensor Circuit
-----	-------------	------------------------------

CIRCUIT DESCRIPTION

See page DI-26, DI-119.

DTC No.	Detection Item	Trouble Area
P0500/21,23	Speed signal is not input to the Engine and ECT ECU while cruise control is set.	<ul style="list-style-type: none"><li>• Combination meter</li><li>• Harness or connector between Engine and ECT ECU and vehicle speed sensor</li><li>• Vehicle speed sensor</li><li>• Engine and ECT ECU</li></ul>

WIRING DIAGRAM

See page DI-26, DI-119.

INSPECTION PROCEDURE

See page DI-26, DI-119.