

REMOVAL

HINT:

For step 1 to 9, refer to [page SR-7](#).

1. REMOVE STEERING WHEEL PAD
2. REMOVE STEERING WHEEL
3. REMOVE FRONT DOOR SCUFF PLATE LH
4. REMOVE COWL SIDE TRIM LH
5. REMOVE FRONT DOOR OPENING TRIM LH
6. REMOVE INSTRUMENT CLUSTER FINISH PANEL
7. REMOVE LOWER NO. 1 PANEL
8. REMOVE COLUMN UPPER AND LOWER COVERS
9. REMOVE SPIRAL CABLE