



**2UZ-FE:****1FZ-FE, 1HZ, 1HD-T, 1HD-FTE:**R00427  
F05664

F05665

**INSPECTION****1. CHECK FLUID LEVEL**

- (a) Keep the vehicle level.
- (b) With the engine stopped, check the fluid level in the oil reservoir.



If necessary, add fluid.

**Fluid: ATF DEXRON® II or III****HINT:**

Check that the fluid level is within the HOT LEVEL range on the reservoir/reservoir cap dipstick.

If the fluid is cold, check that it is within the COLD LEVEL range.


- (c) Start the engine and run it at idle.
- (d) Turn the steering wheel from lock to lock several times to boost fluid temperature.

**Fluid temperature: 80°C (176°F)****Normal****Abnormal**

R07281

- (e) Check for foaming or emulsification.

If there is foaming or emulsification, bleed power steering system. (See page SR-4)

**5 mm (0.20 in.) or less**

R11961

- (f) With the engine idling, measure the fluid level in the oil reservoir.

- (g) Stop the engine.

- (h) Wait a few minutes and remeasure the fluid level in the oil reservoir.

**Maximum fluid level rise: 5 mm (0.20 in.)**

If a problem is found, bleed power steering system.

(See page SR-4)

- (i) Check the fluid level.

**2. CHECK STEERING FLUID PRESSURE**

- (a) Disconnect the pressure feed tube from the PS valve pump.

1FZ-FE: (See page SR-41)

2UZ-FE [Europe]: (See page SR-55)

2UZ-FE [Except Europe]: (See page SR-65)


1HZ: (See page SR-77)

1HD-T, 1HD-FTE: (See page SR-89)

- (b) Connect SST, as shown in the illustration below.  
 SST 09640-10010 (09641-01010, 09641-01030, 09641-01060)

**NOTICE:**


**Check that the valve of the SST is in the open position.**



F05666

- (c) Bleed the power steering system.  
(See page SR-4)
- (d) Start the engine and run it at idle.
- (e) Turn the steering wheel from lock to lock several times to boost fluid temperature.

**Fluid temperature:** 80°C (176°F)




- (f) With the engine idling, close the valve of the SST and observe the reading on the SST.

**Minimum fluid pressure:**

**8,336 kPa (85 kgf/cm<sup>2</sup> 1,209 psi)**

**NOTICE:**

- Do not keep the valve closed for more than 10 seconds.
- Do not let the fluid temperature become too high.



- (g) With the engine idling, open the valve fully.


- (h) Measure the fluid pressure at engine speeds of 1,000 rpm and 3,000 rpm.

**Difference fluid pressure:**

**490 kPa (5 kgf/cm<sup>2</sup> 71 psi) or less**

**NOTICE:**

**Do not turn the steering wheel.**



- (i) With the engine idling and valve fully opened, turn the steering wheel to full lock.

**Minimum fluid pressure:**

**8,336 kPa (85 kgf/cm<sup>2</sup> 1,209 psi)**

**NOTICE:**

- Do not maintain lock position for more than 10 seconds.
- Do not let the fluid temperature become too high.

- (j) Disconnect the SST.

- (k) Connect the pressure feed tube to the PS vane pump.

1FZ-FE: (See page SR-52)

2UZ-FE [Europe]: (See page SR-62)

2UZ-FE [Except Europe]: (See page SR-73)

1HZ: (See page SR-85)

1HD-T, 1HD-FTE: (See page SR-97)

- (l) Bleed the power steering system.

(See page SR-4)