

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit for that code listed in the table below. For details of each code, turn the page referred to under the "See page" for the respective DTC No. in the DTC chart.

| DTC No. (See Page) | Detection Item | Trouble Area |
|-----------------------|------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B2602 (DI-418) | Key unlock warning switch malfunction | <ul style="list-style-type: none"> • Key unlock warning switch |
| B2603 (DI-419) | Tilt and telescopic manual switch malfunction | <ul style="list-style-type: none"> • Tilt and telescopic manual switch circuit • Tilt and telescopic ECU |
| B2610 (DI-421) | Tilt position sensor or tilt motor malfunction | <ul style="list-style-type: none"> • Sensor power source circuit • Actuator power source circuit • Tilt motor circuit • Tilt and telescopic ECU |
| B2611 (DI-423) | Telescopic position sensor or telescopic motor malfunction | <ul style="list-style-type: none"> • Sensor power source circuit • Actuator power source circuit • Telescopic motor circuit • Tilt and telescopic ECU |
| B2620 (DI-425) | ECU power source circuit malfunction | <ul style="list-style-type: none"> • Battery • ECU power source circuit • Tilt and telescopic ECU |
| B2621 (DI-428) | Communication Interruption | <ul style="list-style-type: none"> • Multiplex communication system • Tilt and telescopic ECU |