

<b>DTC</b>	<b>C1252 / 52</b>	<b>Hydraulic brake booster Pump Motor ON Time Abnormally Long</b>
------------	-------------------	---


## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1252 / 52	After the ignition switch has been turned ON, when the power is supplied to the pump motor for more than 5 minutes.	<ul style="list-style-type: none"><li>• Hydraulic brake booster pump motor</li><li>• Hydraulic brake booster pump motor circuit</li><li>• Pressure switch (PH or PL)</li></ul>

Fail safe function:

If trouble occurs in the pump motor, the ECU cuts off current to the ABS solenoid relay and prohibits ABS control.


## WIRING DIAGRAM



F05593

## INSPECTION PROCEDURE

## 1 Check operation of hydraulic brake booster pump motor.

**PREPARATION:**

Disconnect the 2 connectors from hydraulic brake booster connector.

**CHECK:**

Connect positive  $\oplus$  lead to BM1 or BM2 terminal and negative  $\ominus$  lead to EM1 or EM2 terminal of the hydraulic brake booster (pump motor) connector.

**OK:**


The operation sound of the pump motor should be heard.

OK

Go to step 3.

NG

## 2 Check continuity between GND terminal of hydraulic brake booster (pump motor) connector and body ground.

**CHECK:**

Check continuity between EM1 or EM2 terminal of hydraulic brake booster (pump motor) connector and body ground.

**OK:**

Continuity

NG

Repair or replace harness or connector.

OK

Replace hydraulic brake booster pump motor.

3	Check for short circuit in harness and connector between hydraulic brake booster (pump motor) and ABS ECU (See page IN-24).
---	---

NG

Repair or replace harness or connector.

OK

4	Check for short circuit (to B+) in harness and connector between MT of hydraulic brake booster and ABS ECU (See page IN-24).
---	--

OK

Check and replace ABS ECU.

NG

5	Check pressure switch (PH).
---	-----------------------------

#### IN CASE OF USING HAND-HELD TESTER:

##### PREPARATION:

- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and push the hand-held tester main switch ON.
- Select the DATALIST mode on the hand-held tester.

##### CHECK:

Depress the brake pedal more than 40 times with the ignition switch OFF then turn the ignition switch ON and check the pressure switch (PH) condition.

##### HINT:

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

##### OK:


"OFF" turns to "ON".

##### HINT:

OFF: Low pressure

ON: High pressure

#### IN CASE OF NOT USING HAND-HELD TESTER:



##### PREPARATION:

- Disconnect the connector from the hydraulic brake booster.
- With ignition switch OFF, depress the brake pedal more than 40 times to decrease the accumulator pressure.

##### HINT:

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

**CHECK:**

Measure resistance between terminals PH and PHG of hydraulic brake booster connector.

**OK:**

**Resistance: 1 kΩ**

**PREPARATION:**

- (a) Connect the connector to the hydraulic brake booster.
- (b) Disconnect the connector after ignition switch has been ON and the pump motor has been stopped.

**CHECK:**

Measure resistance between terminals PH and PHG of hydraulic brake booster connector.

**OK:**

**Resistance: 0 Ω**

**HINT:**

After inspection, clear the DTC (See page DI-312).

**NG**

**Replace hydraulic brake booster.**

**OK**

**6**

**Check pressure switch (PL).**

**IN CASE OF USING HAND-HELD TESTER:****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

**CHECK:**

Depress the brake pedal more than 40 times with the ignition switch OFF then turn the ignition switch ON and check the pressure switch (PL) condition.

**HINT:**

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

**OK:**


**"OFF" turns to "ON".**

**HINT:**

OFF: Low pressure

ON: High pressure

**IN CASE OF NOT USING HAND-HELD TESTER:**



**PREPARATION:**

- Disconnect the connector from the hydraulic brake booster.
- With ignition switch OFF, depress the brake pedal more than 40 times to decrease the accumulator pressure.

**HINT:**

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

**CHECK:**

Measure resistance between terminals PL and PLG of hydraulic brake booster connector.

**OK:**

**Resistance: 5.7 kΩ**

**PREPARATION:**

- Connect the connector to the hydraulic brake booster.
- Disconnect the connector after ignition switch has been ON and the pump motor has been stopped.

**CHECK:**

Measure resistance between terminals PL and PLG of hydraulic brake booster connector.

**OK:**

**Resistance: 1.0 kΩ**

**HINT:**

After inspection, clear the DTC (See page DI-312).

**NG**

**Replace hydraulic brake booster.**

**OK**

**7**


**Check for open and short circuit in harness and connector between pressure switch and ABS ECU (See page IN-24).**

**NG**

**Repair or replace harness or connector.**

**OK**

8 Check ABS motor relays.



**PREPARATION:**  
Remove the 2 ABS motor relays from Engine Room R/B No. 2.

**CHECK:**  
Check continuity between each pair of terminal of motor relay.  
**OK:**

Terminals 3 and 4	Continuity (Reference value 1)
Terminals 1 and 2	Open

\*1: Motor relay 1 62Ω  
Motor relay 2 54Ω

**CHECK:**  
(a) Apply battery voltage between terminals 3 and 4.  
(b) Check continuity between terminals.

**OK:**

Terminals 1 and 2	Continuity
-------------------	------------

NG Replace ABS motor relay.

OK

9 Check for short circuit in harness and connector between ABS motor relay and ABS ECU (See page IN-24).

NG Repair or replace harness or connector.

OK

Check and replace ABS ECU.