

INSTALLATION

INSTALL FRONT SEAT

- (a) Slide the front seat to the most front position.

NOTICE:

Make sure that seat adjuster locks.

- (b) Without holding the seat track adjuster handle, mount the seat to the vehicle.

HINT:

If holding the seat track adjuster handle, the adjusted most front position slip off.

- (c) Connect the connector.
- (d) Tighten the bolts on the rear side temporarily, tighten them completely starting from the bolts on the inner side.

Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)

- (e) Slide the seat to the most rear position to install the bolts on the front side.

Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)