

Neutral Signal Circuit


CIRCUIT DESCRIPTION

This circuit sends the Neutral start switch Neutral or other to the wiper control ECU.


HINT:

Refer to the Automatic Transmission section for the Neutral start switch check.

WIRING DIAGRAM




RHD Models (1HD-FTE Europe):




C

I25578

RHD Models (1HD-FTE Australia):




125578

LHD Models (1HD-FTE Europe):

C

I25578


LHD Models (2UZ-FE):



C

I25578

LHD Models (1HD-FTE General):



C

I25578

INSPECTION PROCEDURE

1	Check PNP signals using hand-held tester.
---	---

PREPARATION:

Connect the hand-held tester to the DLC3.

(a) Connect the hand-held tester to the DLC3.

(b) Turn the ignition switch ON and push the hand-held tester main SW ON.

CHECK:

Select the item "NSW SW" in the DATA LIST and read its value displayed.

OK:

PNP switch position N: ON

PNP switch position except N: OFF

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-930).

NG

Repair or replace harness and connector between park/neutral position switch and wiper control ECU (See page IN-38).