

<b>DTC</b>	<b>P0773/64</b>	<b>Shift Solenoid E Electrical Malfunction (SL Solenoid Valve)</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION


The SL solenoid valve is turned ON and OFF by signals from the Engine and ECT ECU to control the hydraulic pressure acting on the lock-up relay valve, which then controls operation of the lock-up clutch.

DTC No.	DTC Detecting Condition	Trouble Area
P0773/64	Either (a) or (b) is detected for 1 time. (a) Solenoid resistance is 8 $\Omega$ or less (short circuit) when the solenoid is energized. (b) Solenoid resistance is 100 k $\Omega$ or more (open circuit) when the solenoid is not energized.	<ul style="list-style-type: none"> <li>• Open or short in SL solenoid valve circuit</li> <li>• SL solenoid valve</li> <li>• Engine and ECT ECU</li> </ul>

Fail safe function

If the Engine and ECT ECU detects a malfunction, it turns the SL solenoid valve OFF.


## WIRING DIAGRAM



D03394

## INSPECTION PROCEDURE

- 1 Measure resistance between terminal SL of Engine and ECT ECU and body ground.

**PREPARATION:**

- (a) Remove the glove compartment door  
(See page BO-127).  
(b) Disconnect the connector from Engine and ECT ECU.

**CHECK:**

Measure resistance between terminal SL of Engine and ECT ECU and body ground.


**OK:**

**Resistance: 11 – 15 Ω at 20 °C (68 °F)**

OK

Check and replace the Engine and ECT ECU  
(See page IN-35).

NG

**2 Check harness and connector between Engine and ECT ECU and automatic transmission solenoid connector.****PREPARATION:**

Disconnect the solenoid connector from the transmission.

**CHECK:**


Check the harness between terminal SL of Engine and ECT ECU and terminal SL of transmission solenoid connector.

**OK:**

**There is no open or short circuit.**

**NG****Repair or replace the harness or connector.****OK**

### 3 Check SL solenoid valve.



#### Electrical Check:

##### PREPARATION:

- Jack up the vehicle.
- Remove the oil pan.
- Disconnect the solenoid connector.
- Remove the SL solenoid valve.

##### CHECK:

- Measure resistance between terminal SL of solenoid valve and solenoid body.
- Connect positive  $\oplus$  lead of the battery to terminal of solenoid connector, negative  $\ominus$  lead of the battery to solenoid body.

##### OK:

- (1) Resistance: 11 – 15  $\Omega$  at 20 °C (68 °F)
- (2) The SL solenoid valve makes operating noise.

#### Mechanical Check:

##### PREPARATION:

- Jack up the vehicle.
- Remove the oil pan.
- Disconnect the solenoid connector.
- Remove the SL solenoid valve.

##### CHECK:

- Applying 490 kPa (5 kgf/cm<sup>2</sup>, 71 psi) of compressed air, check that the solenoid valve does not leak air.
- When battery positive voltage is supplied to the solenoid valve, check that the solenoid valve opens.

##### OK:

- Solenoid valve does not leak air
- Solenoid valve opens

NG

Replace the SL solenoid valve.

OK

Repair or replace the solenoid wire.