


DTC	RrDEF, B/L	Ambient Temperature Sensor Circuit
-----	------------	------------------------------------

CIRCUIT DESCRIPTION

This sensor detects the ambient temperature and sends the appropriate signals to the A/C amplifier.


Blinking light	Detection Item	Trouble Area
RrDEF B/L	Open or short in ambient temperature sensor circuit.	<ul style="list-style-type: none"><li>• Ambient temperature sensor.</li><li>• Harness or connector between ambient temperature sensor and A/C amplifier</li><li>• A/C amplifier</li></ul>

WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check voltage between terminals TAM and FrSG of A/C amplifier.

**PREPARATION:**

Remove A/C amplifier with connectors still connected.

**CHECK:**

- Turn ignition switch ON.
- Measure voltage between terminals TAM and FrSG of A/C amplifier connector at each temperature.

**OK:****Voltage**

at 25°C (77°F) 1.3 – 1.8V

at 40°C (104°F) 0.8 – 1.3V

**HINT:**


As the temperature increases, the voltage decreases.

**NG**

Go to step 2.

**OK**

Proceed to next circuit inspection shown on problem symptoms table (See page DI-859). However, if RrDEF and B/L indicator light is light up, check and replace A/C amplifier.

**2 Check ambient temperature sensor.**

108311

**PREPARATION:**

Disconnect ambient temperature sensor connector.

**CHECK:**

Measure resistance between terminals 1 and 2 of ambient temperature sensor connector at each temperature.

**OK:****Resistance**

at 25°C (77°F) 1.6 – 1.8 kΩ

at 50°C (122°F) 0.5 – 0.7 kΩ

**HINT:**

As the temperature increases, the resistance decreases.

**NOTICE:**

When installing the ambient temperature sensor, be sure to connect the sensor connector before connecting the battery.

**NG****Replace ambient temperature sensor.****OK****3 Check harness and connector between ambient temperature sensor and A/C amplifier (Center ECU) (See page IN-35).****NG****Repair or replace harness or connector.****OK****Check and replace and A/C amplifier.**