



- S 14 Sub Fuel Pump
- S 15 Sub Fuel Pump Forcing Driving Relay
- S 16 Sub Fuel Sender
- S 21 Side Airbag Sensor Front LH
- S 22 Side Airbag Sensor Front RH
- S 23 Side Airbag Sensor Rear LH
- S 24 Side Airbag Sensor Rear RH
- S 25 Stereo Component Amplifier
- S 26 Stereo Component Amplifier

- T 17 Tire Carrier Courtesy SW
- T 19 Tweeter LH
- T 20 Tweeter RH
- T 26 Theft Deterrent Siren
- T 27 Television Camera
- T 28 Television Camera ECU
- T 29 Television Camera ECU

- V 18 Vanity Light LH
- V 19 Vanity Light RH

- W 13 Woofer (Speaker)

- Z 8 Option Connector (Microphone)
- Z 9 Option Connector (Trailer Towing)

Position of Parts in Body <RHD Liftgate Type>

