

INSTALLATION

Installation is in the reverse order of removal (See page SA-135).

AFTER INSTALLATION, CHECK FRONT WHEEL ALIGNMENT (See page SA-9)