

The diagram illustrates the electrical system for the Key Reminder and Seat Belt Warning, organized into three main sections: Power Source, Key Reminder, and Moon Roof.

- Power Source:**
  - Includes the BATTERY, F17 FUSIBLE LINK BLOCK (100A J/B NO. 2, 140A ALT), and various fuses (15A GAUGE, 20A A.C., 80A AM1 NO. 1, 20A AM1 NO. 2).
  - Key components include the ACC, IG1, and IG2 relays, and the 126 IGNITION SW.
- Key Reminder:**
  - Features the COMBINATION METER with SEAT BELT and SEAT BELT WARNING indicators.
  - Includes the SEAT BELT WARNING OCCUPANT DETECTION SENSOR (S17) and BUCKLE SW RH (B11).
  - Wiring paths lead to the front and rear seat headrests for EC (right cylinder head) and ED (rear bank of left cylinder head) warnings.
- Moon Roof:**
  - Includes the M1 MOON ROOF CONTROL ECU and M2 MOON ROOF CONTROL SW.
  - Features the POWER RELAY and various switches (UP, DOWN, OPEN, CLOSE).
  - Wiring paths lead to the front and rear seat headrests for the front side under the front seat RH and front left side of fender apron.

The diagram uses a color-coded system (R-L, SB, B, L-B, G, W-B, BK, EE) to identify the wires and their connections throughout the system.