

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	A45	ABS Speed Sensor Rear LH (Independent Suspension)	90980-11073
A 2	A/C Condenser Fan Motor	90980-11237		ABS Speed Sensor Rear LH (Rigid Axle Suspension)	90980-11075
A 4	Pressure SW (w/ Rear A/C)	90980-10943		A46	ABS Speed Sensor Rear RH (Independent Suspension)
	Pressure SW (w/o Rear A/C)	90980-11149	ABS Speed Sensor Rear RH (Rigid Axle Suspension)		90980-11075
A 5	A/C Magnetic Clutch	90980-11271	A47		Accumulator Solenoid
A 6	A/C Magnetic Clutch and Lock Sensor	90980-11016	A48	ABS & BA & TRC & VSC Actuator	90980-11413
A 7	A/C Magnetic Valve	90980-11075	A49	ABS & BA & TRC & VSC Actuator	90980-10895
A 9	A/T Oil Temp. Sensor	90980-11243	A50	ABS & BA & TRC & VSC Actuator	90980-11151
A10	ABS Actuator	90980-11413	A51	ABS & BA & TRC & VSC Actuator	90980-11009
A11	ABS Actuator	90980-10895	A52	ABS & BA & TRC & VSC ECU	90980-11935
A12	ABS Actuator	90980-11151	A53	ABS & BA & TRC & VSC ECU	90980-11476
A13	ABS Actuator	90980-11009	A54	ABS & BA & TRC & VSC ECU	90980-11637
A15	ABS Speed Sensor Front LH	90980-10941	A55	ABS & BA & TRC & VSC ECU	90980-11638
A16	ABS Speed Sensor Front RH	90980-11002	A56	ADD Control Motor	90980-11024
A17	Accel Position Sensor (1HD-FTE)	90980-11232	A57	A/C Control Assembly	90980-12170
	Accel Position Sensor (2UZ-FE)	90980-11144	A58	A/C Control Assembly	90980-11913
A18	AHC Pump Motor	90980-10928	A59	A/C Control Assembly	90980-11927
A19	Air Cleaner Warning Sensor	90980-11025	A60	A/T Shift Lever Illumination	90980-11911
A20	Air Flow Meter	90980-11317		Shift Lock Control ECU	
A21	Airbag Sensor Front LH	90980-11856	A61	ADD Control Relay	90980-10801
A22	Airbag Sensor Front RH		A62	Airbag Sensor Assembly (w/ Side Airbag)	82824-50150
A23	Alternator (1HD-FTE, 1HZ)	90980-09213		Airbag Sensor Assembly (w/o Side Airbag)	90980-11871
	Alternator (2UZ-FE, 1FZ-FE)	90980-09212	A63	Airbag Sensor Assembly (w/ Side Airbag)	82824-50160
A24	Alternator	90980-11349		Airbag Sensor Assembly (w/o Side Airbag)	90980-11873
A25	Auto Antenna Motor	90980-11194	A64	Auto Wiper ECU	90980-10801
A26	A/C Solar Sensor	90980-11919		Short Connector	
A27	A/C Thermistor	90980-11918	A65	Auto Wiper ECU	90980-12183
A28	ABS Deceleration Sensor	90980-10845	A66	Automatic Light Control Sensor	90980-12056
A29	ABS ECU	90980-11424	A67	Airbag Sensor Assembly	90980-11872
A30	ABS ECU	90980-11391	B 1	Back-Up Light SW (Except 1HZ)	90980-11051
A31	ABS ECU	90980-11390		Back-Up Light SW (1HZ)	90980-11250
A32	Accelerator Pedal SW	90980-10825	B 2	Brake Fluid Level Warning SW	90980-11207
A33	AHC Main Relay	90980-10171	B 3	Blower Motor Controller (LHD, RHD Europe)	90980-10910
A34	Air Inlet Control Servo Motor	90980-11909		Blower Motor Controller (RHD Except Europe)	90980-11667
A35	Air Mix Control Servo Motor (LHD)	90980-10797	B 4	Blower HI Relay	90980-10713
	Air Mix Control Servo Motor (RHD)	90980-11529	B 5	Blower LO Relay	90980-10171
A36	Air Vent Mode Control Servo Motor (LHD)	90980-11165	B 6	Blower ME Relay	
	Air Vent Mode Control Servo Motor (RHD)	90980-11321	B 7	Back Door Courtesy SW (Liftgate Type)	90980-10039
A37	Airbag Squib (Front Passenger Airbag Assembly)	90980-12160		Back Door Courtesy SW (Swing Type)	90980-11367
A38	Airbag Squib (Steering Wheel Pad)		B 8	Back Door Key Lock and Unlock SW (Liftgate Type)	90980-11490
A39	Ashtray Illumination	90980-10825		Back Door Key Lock and Unlock SW (Swing Type)	90980-11169
A40	Auto Antenna Control Relay	90980-10819			
A41	A/C Amplifier	90980-11497			
A42	A/C Amplifier	90980-11475			
A43	A/C Amplifier	90980-11502			
A44	A/C Amplifier	90980-10801			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
B 9	Back Door Lock Motor and Back Door Unlock Detection SW	90980-11150	D10	Damping Force Control Actuator Front LH	90980-11960
B10	Buckle SW LH	90980-11169	D11	Damping Force Control Actuator Front RH	
B11	Buckle SW RH		D12	Damping Force Control Actuator Rear LH	
B12	Body ECU	90980-12151	D13	Damping Force Control Actuator Rear RH	
B13	Body ECU	90980-12149	D14	Detection SW (Rear Diff. Lock) (Independent Suspension)	90980-11156
B14	Body ECU	90980-12150		Detection SW (Rear Diff. Lock) (Rigid Axle Suspension)	90980-11250
B15	Buckle SW LH	90980-11599	D15	Door Courtesy Light Front LH	90980-11148
	Seat Position Sensor		D16	Door Courtesy Light Front RH	
B16	Buckle SW RH		D17	Door Courtesy Light Rear LH	
	Seat Position Sensor		D18	Door Courtesy Light Rear RH	
C 1	Camshaft Position Sensor	90980-10947	D19	Door Courtesy SW Front LH	90980-10871
C 2	Center Diff. Lock Control Motor	90980-11024	D20	Door Courtesy SW Front RH	
C 3	Check Connector	90980-11195	D21	Door Courtesy SW Rear LH	
C 4	Crankshaft Position Sensor (1FZ-FE)	90980-11016	D22	Door Courtesy SW Rear RH	
	Crankshaft Position Sensor (1HD-FTE)	90980-11162	D23	Door Key Lock and Unlock SW LH	90980-11170
	Crankshaft Position Sensor (2UZ-FE)		D24	Door Key Lock and Unlock SW RH	
C 6	CD Automatic Changer (LHD)	90980-10803	D25	Door Lock Motor Front LH	90980-11150
	CD Automatic Changer (RHD)	90980-12200		Door Unlock Detection SW Front LH	
C 8	Center Diff. Lock Control Relay	90980-10801	D26	Door Lock Motor Front RH	
C13	Cigarette Lighter	90980-10760		Door Unlock Detection SW Front RH	
C14	Cigarette Lighter Illumination	90980-11148	D27	Door Lock Motor Rear LH	
C15	Combination Meter	82824-60060		Door Unlock Detection SW Rear LH	
C16	Combination Meter	82824-60050	D28	Door Lock Motor Rear RH	
C17	Combination Meter	82824-60060		Door Unlock Detection SW Rear RH	
C18	Combination Meter	82824-60050	D29	Driving Position Memory SW	90980-10601
C19	Combination SW (LHD, RHD Europe)	90980-11672	D30	Detection SW (Front Diff. Lock)	90980-11250
	Combination SW (RHD Except Europe)	90980-11671	D32	Diesel Throttle Position SW	90980-11038
C20	Combination SW	90980-12155	D33	Deceleration Sensor	90980-12080
C22	Combination SW	90980-11594	D34	Diode (Front Fog No.2)	90980-10637
C23	Cooler Box	90980-11535	D35	Diode (Viscous Heater1)	
C24	Cruise Control Clutch SW	90980-10906	D36	Diode (Viscous Heater2)	
C26	Control Valve Assembly	90980-11599	D37	Double Lock Control Relay	90980-10807
C32	Center Cluster Integration Panel	90980-12200	D38	Door Control Receiver	90980-11909
C33	Combination SW	90980-12183	D39	Door Lock Motor Front LH	90980-10890
C35	Curtain Shield Airbag Squib LH	90980-11864		Door Unlock Detection SW Front LH	
C36	Curtain Shield Airbag Squib RH			Double Lock Motor Front LH	
D 1	Detection SW (Center Diff. Lock)	90980-11250		Double Lock Position SW Front LH	
D 2	Detection SW (Transfer L Position)		D40	Door Lock Motor Front RH	
D 3	Detection SW (Transfer Neutral Position)	90980-11025		Door Unlock Detection SW Front RH	
D 4	Diesel Engine Revolution Sensor	90980-11250		Double Lock Motor Front RH	
D 5	Damping Mode Select SW and Height Control SW	90980-11923		Double Lock Position SW Front RH	
D 7	Diode (Front Fog No.1)	90980-10637	D41	Door Lock Motor Rear LH	90980-10891
D 8	DLC3	90980-11665		Door Unlock Detection SW Rear LH	
D 9	Door Lock Control SW (LHD)	90980-10797		Double Lock Motor Rear LH	
	Door Lock Control SW (RHD)	90980-10996		Double Lock Position SW Rear LH	

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
D42	Door Lock Motor Rear RH	90980-10891	F 7	Front Side Turn Signal Light LH	90980-11162
	Door Unlock Detection SW Rear RH		F 8	Front Side Turn Signal Light RH	
	Double Lock Motor Rear RH		F 9	Front Turn Signal Light LH	90980-11019
	Double Lock Position SW Rear RH		F10	Front Turn Signal Light RH	
E 1	ECT Solenoid (1FZ-FE)	90980-10854	F11	Front Wiper Motor	90980-11599
	ECT Solenoid (2UZ-FE, 1HD-FTE)	90980-12293	F12	Fuel Cut Valve Controller	90980-11349
E 2	EFI Water Temp. Sensor (1FZ-FE, 1HD-FTE)	90980-10737	F13	Fuel Heater SW	90980-10928
	EFI Water Temp. Sensor (2UZ-FE)	90980-10736	F14	Fuel Pump Resistor	90980-11156
E 3	Engine Hood Courtesy SW	90980-11003	F15	Fuel Sediment SW	90980-11003
E 6	ECT Pattern Select SW	90980-10933	F16	Fuel Temp. Sensor	90980-10737
E 7	Engine and ECT ECU	90980-12144	F17	Fusible Link Block	82675-60050
	Engine ECU		F19	Front Blower Motor	90980-10903
E 8	Engine and ECT ECU	90980-12145	F20	Front Blower Resistor (LHD)	90980-10910
	Engine ECU			Front Blower Resistor (RHD)	90980-11136
E 9	Engine and ECT ECU	90980-12143	F21	Front/Rear Diff. Lock Control SW	90980-10631
	Engine ECU		F22	Fuel Tank Changeover SW	90980-10933
E10	Engine and ECT ECU	90980-12146	F23	Front Door Speaker LH	90980-10935
	Engine ECU		F24	Front Door Speaker RH	
E11	Engine and ECT ECU	90980-12142	F25	Front Interior Light	
	Engine ECU		F26	Front Personal Light	90980-10825
E12	Engine and ECT ECU	90980-11391	F27	Front/Rear Diff. Lock Control ECU	90980-10848
	Engine ECU		F28	Fuel Pump	90980-11077
E13	Engine and ECT ECU	90980-11390			
	Engine ECU		F30	Fuel Pump Select Relay	90980-10173
E14	Engine and ECT ECU	90980-11392	F31	Fuel Solenoid Valve 1	90980-10901
	Engine ECU		F32	Fuel Solenoid Valve 2	
E15	EDU	90980-11024	F33	Front Diff. Lock Motor	90980-11290
E16	Engine and ECT ECU	90980-12144	F35	Fuel Pump Resistor LH	90980-11156
	Engine ECU		F36	Fuel Pump Resistor RH	
E17	Engine and ECT ECU	90980-12145	F37	Fusible Link Block	90980-11996
	Engine ECU		F38	Fusible Link Block	90980-11881
E18	Engine and ECT ECU	90980-12146	F39	Fusible Link Block	90980-11775
	Engine ECU		F40	Fusible Link Block	90980-10995
E19	Engine and ECT ECU	90980-12142	G 1	Glow Plug	99141-13004
	Engine ECU		G 2	Glow Plug Relay	90980-11569
E20	Engine and ECT ECU	90980-11129	G 3	Glove Box Light	90980-11098
	Engine ECU		G 4	Gateway ECU	90980-11911
E21	Emission Control ECU	90980-11390	H 1	Headlight Beam Level Control Actuator LH	90980-11016
E22	Emission Control ECU	90980-11391	H 2	Headlight Beam Level Control Actuator RH	
F 1	First Position SW	90980-10923	H 3	Headlight Cleaner Control Relay	90980-10939
F 2	Fluid Pressure Sensor	90980-11451	H 4	Headlight Cleaner Motor	90980-11410
F 3	Front Clearance Light LH	90980-11156	H 5	Headlight Control ECU LH	90980-11255
F 4	Front Clearance Light RH		H 6	Headlight Control ECU RH	
F 5	Front Fog Light LH	90980-11660	H 7	Headlight LH (High)	90980-11659
F 6	Front Fog Light RH		H 8	Headlight RH (High)	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
H 9	Headlight LH (Low)	90980-11660	J 1	Junction Connector	90980-11915
H10	Headlight RH (Low)		J 2	Junction Connector	
H11	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869	J 3	Junction Connector	
H12	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028	J 4	Junction Connector	
H13	Heated Oxygen Sensor (Bank 2 Sensor 1)	90980-10869	J 5	Junction Connector	90980-11398
H14	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11028	J 6	Junction Connector	90980-11927
H15	Height Control Sensor Front LH	90980-11015	J 7	Junction Connector	
H16	Height Control Sensor Front RH		J 8	Junction Connector	90980-11661
H17	Horn LH	90980-10619	J 9	Junction Connector	
H18	Horn RH		J10	Junction Connector	
H19	Headlight Beam Level Control SW	90980-10996	J11	Junction Connector	
H20	Height Control Sensor Rear	90980-11143	J12	Junction Connector	90980-10803
H21	High Mounted Stop Light (Liftgate Type)	90980-11211	J13	Junction Connector	
	High Mounted Stop Light (Swing Type)	90980-10825	J14	Junction Connector	90980-11398
H22	Heated Oxygen Sensor	90980-11028	J15	Junction Connector	
H23	Headlight Cleaner SW	90980-12063	J16	Junction Connector	
I 1	Ignition Coil and Igniter No.1 (1FZ-FE)	90980-11150	J17	Junction Connector	
	Ignition Coil and Igniter No.1 (2UZ-FE)	90980-11885	J18	Junction Connector	
I 2	Ignition Coil and Igniter No.2 (1FZ-FE)	90980-11150	J19	Junction Connector	90980-11742
	Ignition Coil and Igniter No.2 (2UZ-FE)	90980-11885	J21	Junction Connector	
I 3	Ignition Coil and Igniter No.3 (1FZ-FE)	90980-11150	J22	Junction Connector	90980-11927
	Ignition Coil and Igniter No.3 (2UZ-FE)	90980-11885	J24	Junction Connector	
I 4	Ignition Coil and Igniter No.4	90980-11885	J25	Junction Connector	
I 5	Ignition Coil and Igniter No.5		J26	Junction Connector	
I 6	Ignition Coil and Igniter No.6		J27	Junction Connector	90980-11925
I 7	Ignition Coil and Igniter No.7		J28	Junction Connector	
I 8	Ignition Coil and Igniter No.8	90980-11153	J29	Junction Connector	
I 9	Injection Pump		J30	Junction Connector	90980-11915
I10	Injector No.1		J31	Junction Connector	
I11	Injector No.2		J32	Junction Connector	
I12	Injector No.3		J33	Junction Connector	
I13	Injector No.4		J34	Junction Connector	90980-11166
I14	Injector No.5		K 1	Knock Sensor 1	
I15	Injector No.6		K 2	Knock Sensor 2	90980-11159
I16	Injector No.7		L 1	License Plate Light	
I17	Injector No.8		L 2	License Plate Light LH	90980-11148
I18	Intake Air Temp. Sensor (1FZ-FE)	90980-11163	L 3	License Plate Light RH	
	Intake Air Temp. Sensor (1HD-FTE)	90980-11025	L 4	Lumbar Support Control SW (Driver's Seat)	90980-10601
I19	Intake Heater	99141-14006	L 5	License Plate Light No.1	90980-11159
I20	Intake Heater Relay	90980-11248	L 6	License Plate Light No.2	90980-10871
I21	Intake Heater Relay	99141-14006	M 1	Moon Roof Control ECU	90980-10997
I22	Intake Heater Relay		M 2	Moon Roof Control SW	90980-10789
I23	ISC Valve	90980-11145	M 3	Master Cylinder Pressure Sensor	90980-11451
I24	Idle-Up SW	90980-10933	M 4	Multi-Display (w/ Navigation System)	90980-12203
I26	Ignition SW	90980-11615		Multi-Display (w/o Navigation System)	90980-12094
I30	Inner Mirror	90980-11186	M 5	Multi-Display	90980-12410

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
N 1	A/T Indicator Light SW (1FZ-FE)	90980-11332	P31	Power Seat Motor (Driver's Seat Slide Control)	90980-10825
	A/T Indicator Light SW (2UZ-FE, 1HD-FTE)	90980-11784	P32	Power Seat Motor (Front Passenger's Seat Front Vertical Control)	
	Neutral Start SW (1FZ-FE)	90980-11332	P33	Power Seat Motor (Front Passenger's Seat Rear Vertical Control)	
	Neutral Start SW (2UZ-FE, 1HD-FTE)	90980-11784	P34	Power Seat Motor (Front Passenger's Seat Reclining Control)	
N 2	Noise Filter (Ignition)	90980-10843	P35	Power Seat Motor (Front Passenger's Seat Slide Control)	
N 4	Navigation ECU	90980-11973	R 2	Radio and Player	90980-10997
N 5	Navigation ECU	90980-11923	R 3	Radio and Player	90980-10803
N 6	Noise Filter (ABS)	90980-10983	R 4	Radio and Player	90980-10996
N 7	Navigation ECU	90980-12221	R 6	Rear Diff. Lock Control ECU	90980-10801
O 2	O/D Main SW	90980-11606	R 7	Rear Fog Light SW	90980-12113
O 3	Oil Level Sensor (1FZ-FE)	90980-11235	R 9	Remote Control Mirror SW	90980-11657
	Oil Level Sensor (1HD-FTE, 1HZ)	90980-10532	R10	Remote Control Mirror SW	90980-11319
	Oil Level Sensor (2UZ-FE)		R11	Rheostat (Except Optitron Meter)	90980-10908
O 4	Oil Pressure Sender (1HD-FTE, 1HZ)	90980-10703		Rheostat (Optitron Meter)	90980-10799
	Oil Pressure Sender (2UZ-FE, 1FZ-FE)	90980-11363	R12	Room Temp. Sensor (Front)	90980-11918
O 5	Overhead J/B	90980-11909	R13	Rear A/C Control SW (Rear Automatic A/C)	90980-11503
O 6	Overhead J/B	90980-12155			Rear A/C Control SW (Rear Manual A/C)
P 1	Pick-Up Sensor	90980-11157	R14	Rear Air Mix Control Servo Motor	90980-11319
P 2	Power Steering Oil Pressure SW	90980-11428	R15	Rear Combination Light LH	90980-11587
P 3	Power Outlet (Front)	90980-10760	R16	Rear Combination Light LH (w/ Rear Fog Light)	90980-10825
P 6	Pre-Heating Timer	90980-10803			Rear Combination Light LH (w/o Rear Fog Light)
P 7	Parking Brake SW	90980-10871	R17	Rear Combination Light RH	90980-11587
P 8	Power Outlet (Luggage Compartment)	90980-10860	R18	Rear Combination Light RH (w/ Rear Fog Light)	90980-10825
P11	Power Window Control SW Front LH	90980-11947			Rear Combination Light RH (w/o Rear Fog Light)
P12	Power Window Control SW Front RH		R19	Rear Cooler Blower Motor	90980-10214
P13	Power Window Control SW Rear LH		R20	Rear Cooler Magnetic Valve	90980-10860
P14	Power Window Control SW Rear RH		R21	Rear Cooler Power Transistor	90980-10171
P15	Power Window Master SW	90980-12166	R22	Rear Cooler Relay	
P17	Power Window Motor Front LH	90980-11599	R23	Rear Diff. Lock Motor (Independent Suspension)	90980-11194
P18	Power Window Motor Front RH				Rear Diff. Lock Motor (Rigid Axle Suspension)
P19	Power Window Motor Rear LH		R24	Rear Door Speaker LH	90980-10935
P20	Power Window Motor Rear RH		R25	Rear Door Speaker RH	
P21	Pretensioner LH	90980-11862	R26	Rear Evaporator Temp. Sensor	90980-11918
P22	Pretensioner RH		R27	Rear Heater Blower Motor	90980-10860
P23	Power Seat Control SW (Driver's Seat) (w/ Driving Position Memory)	90980-11909	R28	Rear Heater Blower Resistor	90980-10916
	Power Seat Control SW (Driver's Seat) (w/o Driving Position Memory)	90980-10803	R29	Rear Heater Control SW	90980-10797
P24	Power Seat Control SW (Front Passenger's Seat)	90980-10803	R30	Rear Heater Power Transistor	90980-10171
P27	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825	R31	Rear Heater Relay	
P28	Power Seat Motor (Driver's Seat Lumbar Support Control)		R32	Rear Inlet Air Temp. Sensor	90980-11369
P29	Power Seat Motor (Driver's Seat Rear Vertical Control)				
P30	Power Seat Motor (Driver's Seat Reclining Control)				

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
R33	Rear Interior Light	90980-10935	S15	Sub Fuel Pump Forcing Driving Relay	90980-10171
R34	Rear Personal Light (w/ Moon Roof)	90980-12211	S16	Sub Fuel Sender	90980-11016
	Rear Personal Light (w/o Moon Roof)	90980-10365	S17	Seat Belt Warning Occupant Detection Sensor	90980-10860
R35	Rear Window Defogger	90980-11097		S18	Seat Heater (Driver's Seat)
R36	Rear Window Defogger		S19	Seat Heater (Front Passenger's Seat)	
R37	Rear Window Defogger LH	90980-10792	S20	Swirl Control Valve	90980-11156
R38	Rear Window Defogger LH		S21	Side Airbag Sensor Front LH	90980-12225
R39	Rear Window Defogger RH		S22	Side Airbag Sensor Front RH	
R40	Rear Window Defogger RH		S23	Side Airbag Sensor Rear LH	
R41	Rear Wiper Motor	90980-10795	S24	Side Airbag Sensor Rear RH	
R42	Rear Wiper Motor LH		S25	Stereo Component Amplifier	90980-10848
R43	Rear Wiper Motor RH		S26	Stereo Component Amplifier	90980-11877
R44	Rear Wiper Relay (Liftgate Type)	90980-10797	S27	Seat Heater (Driver's Seat Cushion)	90980-10794
	Rear Wiper Relay (Swing Type)	90980-10801	S28	Seat Heater (Front Passenger's Seat Cushion)	
R47	Remote Control Mirror ECU	90980-11877	S29	Seat Position Sensor	90980-12195
R48	Remote Control Mirror LH	90980-11573	S30	Side Airbag Squib LH	90980-11864
R49	Remote Control Mirror RH		S31	Side Airbag Squib RH	
R50	Room Temp. Sensor (Rear)	90980-11918	S32	Seat ECU	90980-10801
R53	Radio and Player	90980-12038	T 1	Temp. Sensor (AHC)	90980-10737
R54	Radio and Player	90980-12259	T 2	Theft Deterrent Horn	90980-10619
R55	Radio and Player	90980-12183	T 3	Throttle Control Motor	90980-11144
R56	Rear Diff. Lock Control SW	90980-10631	T 4	Throttle Position Sensor	90980-11261
R57	Rear Seat Audio Controller	90980-12200	T 5	Timing Control Valve	90980-10720
R58	Rain Sensor	90980-12263	T 6	Turbo Pressure Sensor	90980-10845
R59	Rear Cooler Blower Resistor	90980-10171	T 8	Telescopic Motor	90980-10799
R60	Rear Fog Light	90980-10860	T 9	Theft Deterrent ECU	90980-12169
R61	Roll Sensing of Curtain Shield Airbags Cut Off SW	90980-10957	T11	Tilt and Telescopic ECU	90980-10799
S 1	Speed Sensor (Combination Meter)	90980-11143	T12	Tilt and Telescopic ECU	90980-10848
S 2	Speed Sensor (ECT)	90980-11156	T13	Tilt Motor	90980-10799
S 3	Spill Valve	90980-11155	T14	Ignition Key Cylinder Light	90980-12092
S 4	Starter (1FZ-FE)	90980-09506		Transponder Key Amplifier	
	Starter (1HD-FTE, 1HZ)	90980-09508	T15	Transponder Key Computer (1HZ)	90980-12183
	Starter (2UZ-FE)	90980-09585		Transponder Key Computer (2UZ-FE, 1FZ-FE, 1HD-FTE)	90980-11911
S 5	Starter (1HD-FTE, 1HZ)	90980-11184	T16	Turn Signal Flasher	90980-10799
	Starter (2UZ-FE, 1FZ-FE)	90980-11400	T17	Tire Carrier Courtesy SW	90980-10870
S 6	Stop Light SW	90980-11118	T19	Tweeter LH	90980-11300
S 7	Suspension Control ECU	90980-11424	T20	Tweeter RH	
S 8	Suspension Control ECU	90980-11391	T22	TVSS ECU	90980-10803
S 9	Suspension Control ECU	90980-11390	T23	Throttle Control Motor and Sensor	90980-11858
S10	Seat Heater SW (Driver's Seat) (LHD)	90980-10797	T24	Throttle Position Sensor and Timing Control Valve	90980-11599
	Seat Heater SW (Driver's Seat) (RHD)	90980-10996		T25	Turbine Speed Sensor
S11	Seat Heater SW (Front Passenger's Seat) (LHD)	90980-10996	T26	Theft Deterrent Siren	90980-11349
	Seat Heater SW (Front Passenger's Seat) (RHD)	90980-10797	T27	Television Camera	90980-12381
S14	Sub Fuel Pump	90980-11038			

## G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
T28	Television Camera ECU	90980-12169			
T29	Television Camera ECU	90980-10997			
U 1	Unlock Warning SW	90980-10860			
V 1	Vacuum Sensor	90980-10845			
V 2	Vacuum SW	90980-11252			
V 3	Variable Resistor	90980-10902			
V 4	Viscous Heater Magnetic Clutch	90980-11271			
V 6	VRV (EGR)	90980-11162			
V 7	VSV (A/C Idle-Up)	90980-11156			
V 8	VSV (EGR Cut) (1HD-FTE)	90980-11149			
	VSV (EGR Cut) (1HZ)	90980-11156			
V 9	VSV (EVAP)	90980-11156			
V11	VSV (Turbo Pressure Sensor)				
V12	Viscous Heater Amplifier	90980-10801			
V13	VSC Warning Buzzer	90980-10906			
V14	VRV (EGR No.2)	90980-11162			
V15	VSV (BACS)	90980-10572			
V16	VGRS ECU	90980-12120			
V17	VGRS ECU	90980-11915			
V18	Vanity Light LH	90980-11918			
V19	Vanity Light RH				
V20	VGRS Actuator	90980-10993			
W 2	Washer Motor	90980-11294			
W 3	Water Temp. Sender	90980-11428			
W 4	Water Temp. Sensor (Glow Plug)	90980-10737			
W 5	Water Temp. SW (A/C)	90980-10184			
W 7	Winch Main Relay	90980-10887			
W 8	Winch Main Relay	—			
W 9	Winch Main Relay				
W10	Winch Motor and Magnetic SW	90980-10887			
W11	Winch Motor and Magnetic SW	90980-09552			
W13	Woofer (Speaker)	90980-10795			
Z 1	Option Connector (Glass Breakage Sensor)	90980-10799			
Z 3	Option Connector (Radar Sensor)	90980-11013			
Z 4	Option Connector (Cellular Mobile Telephone)	90980-11954			
Z 5	Option Connector (Cellular Mobile Telephone)	90980-12161			
Z 8	Option Connector (Microphone)	90980-11368			
Z 9	Option Connector (Trailer Towing)	90980-10988			
Z10	Option Connector (Wireless Door Lock Buzzer)	90980-11051			

Note: Not all of the above part numbers of the connector are established for the supply.

