

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during DTC check, find the circuit corresponding to the code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
B1244 (DI-994)	Malfunction of light sensor.	<ul style="list-style-type: none">• Light sensor• Wire harness• Body ECU