

INSPECTION

INSPECT RECLINING LOCK POSITION ND SLIDING LOCK POSITION SLIPPING OFF

(a) When reclining the seat , inspect that the outer and inner recliners are released at the same time.

HINT:

When the reclining lock positions slip off, disassemble the seat to adjust the position.

(b) When sliding the seat, inspect that the outer and inner tracks are locked at the same time.

HINT:

When sliding lock positions slip off, loosen the bolts to adjust the position.