

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>P1335/13</b> | <b>Crankshaft Position Sensor Circuit Malfunction (during engine running)</b> |
|------------|-----------------|---|

## CIRCUIT DESCRIPTION

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-72](#).

| DTC No.  | DTC Detecting Condition  | Trouble Area  |
|----------|--|---|
| P1335/13 | No crankshaft position sensor signal to engine ECU with engine speed 1,000 rpm or more | <ul style="list-style-type: none"><li>• Open or short in crankshaft position sensor circuit</li><li>• Crankshaft position sensor</li><li>• Starter</li><li>• Engine ECU</li></ul> |

## WIRING DIAGRAM

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-72](#) for the WIRING DIAGRAM.

## INSPECTION PROCEDURE

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-72](#).