

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Auto wiper system does not operate (All functions).	1. Front wiper switch 2. Front wiper switch circuit 3. Wiper control ECU power source circuit 4. IG switch circuit 5. Front wiper motor circuit 6. Front wiper position circuit 7. Front wiper motor 8. Wiper control ECU	BE-30 DI-953 DI-933 DI-935 DI-956 DI-937 BE-30 IN-38
Raindrop Sensing Function does not operate (When the position is in "Auto", the system becomes vehicle speed-sensing adjustable interval INT function).	1. Rain sensor circuit 2. Rain sensor 3. Wiper control ECU	DI-931 IN-38 IN-38
Vehicle Speed Switching Function does not operate.	1. Neutral signal circuit 2. Stop light switch circuit 3. Wiper control ECU	DI-940 DI-947 IN-38
Washer-Linked Wiper with Drip-Preventive Function does not operate.	1. Front wiper switch (front washer switch) 2. Front washer switch circuit 3. Wiper control ECU	BE-30 DI-950 IN-38